



WMF 5000 S+

USER MANUAL

ENGLISH

Congratulations on the purchase of your WMF coffee machine.

The WMF 5000 S+ coffee machine is a fully automatic single-cup machine for espresso, café crème, cappuccino, milk coffee, latte macchiato, milk foam, and hot water. Thanks to the optional "Fresh Filtered Coffee" extension, the WMF 5000 S+ can also dispense freshly filtered coffee.

With its optionally available powder hopper, the WMF 5000 S+ can also make hot chocolate with milk or milk foam.



Follow the User Manual



- > Read the User Manual carefully prior to use.
- > Please refer to the User Manual, paying special attention to the safety instructions and Safety chapter.
- > Follow the warning instructions on the coffee machine.
- > Ensure that the staff and all users have access to the User Manual.

CAUTION

Follow the User Manual signs and symbols
page 22

Follow the Safety chapter
▷ starting on page 7



Hazard to life due to electrical shock



- The voltage inside the coffee machine is a hazard to life.
 - > Never open the housing.
 - > Never loosen the screws, and do not remove any housing parts.

WARNING

Follow the Safety chapter
▷ starting on page 7



Conditions for use and installation

- In the event of failure to comply with maintenance information and the specifications in the Technical Data chapter, no liability is accepted for any resultant damage.
 - > Follow the User Manual.
 - > Initial start-up, maintenance and repairs may only be carried out by the WMF Service, using original spare parts.

IMPORTANT

Technical data
▷ starting on page 118

Maintenance
▷ starting on page 105

1	Safety	7
1.1	General safety instructions	7
1.2	Intended use	14
1.3	Conditions for use and installation	17
2	Introduction	20
2.1	Parts of the coffee machine	20
	"Ready to operate" display	20
	Glossary	23
3	Operation	24
3.1	Operation safety instructions	24
3.2	Other documents	25
3.3	Switch on the coffee machine	26
3.4	Milk or milk foam	26
	3.4.1 Connect up the milk	26
3.5	Beverage dispensing	27
	Cancel beverage	27
3.6	Fresh Filtered Coffee – FFC (optional)	27
3.7	Pre-selection pads (optional)	28
3.8	Optional pads	28
3.9	Cup size adjustment	28
3.10	Hot water dispensing	28
3.11	Steam dispensing	29
	3.11.1 Auto Steam (optional)	30
	3.11.2 Easy Steam (optional)	30
	3.11.3 SteamJet cup warmer	31
3.12	Height adjustment of the combi spout	32
	Automatic height adjustment	32
	Cup detection (optional)	32
3.13	Bean hopper / powder hopper	32
3.14	Manual insert, lockable	33
3.15	Grounds container	34
3.16	Grounds disposal through the counter (optional)	34
3.17	Drip tray	35
3.18	Switch off the coffee machine	35
4	Software	36
4.1	Overview	36
	Ready to operate	36
	Function bar "Ready to operate" display	36
	Main menu functions	37
	Menu control pads	37
	Messages on the display	37
4.2	"Ready to operate" display	38
	4.2.1 Beverage buttons	38
	4.2.2 Function bar	38
	Hot water button	38
	SteamJet pad	38
	"Warm rinse" pad	39
	Nutritional information	39

Table of Contents

	Cup size adjustment	39
	S-M-L pad	39
	Barista pad - coffee strength	39
	Milk system refill	40
	Second type of coffee (decaf)	40
	Second milk type (optional)	40
	Steam button	40
4.3	Care	41
	System cleaning	41
	Mixer rinsing	41
	Milk system cleaning	41
	Intensive system cleaning (AutoClean)	42
	FFC filter change	42
	Foamer rinsing	42
	CleanLock	42
	Instructions	43
	Milk system refill (Dynamic Milk)	43
	Settings	43
4.4	Beverages	44
	General information	44
	Cup volume, multiple brewing, and dispensing option	45
	Change recipes	47
	Select coffee grinder	50
	Text, picture, and cup height	50
	Change buttons	52
4.5	Operating options	53
	Operating elements	53
	Button layout	56
	PostSelection	57
	Caffeine-free	57
	Beverage pre-selection	58
	Cancel beverage	58
	Milk foam selection	58
	Logo	59
4.6	Information	60
	Last brewing cycle	60
	Timer	60
	Service	60
	Care	60
	Water filter and descaling	60
	Journal	60
4.7	Accounting	61
	Counters	61
	Vending machines	61
	External accounting	61
	Free of charge settings	62
4.8	PIN rights	62
	Cleaning PIN	63
	Settings PIN	63
	Accounting PIN	63
	Re-enter PIN	63

4.9	Timer	64
	Time / date	64
	Timer	64
	Timer overview and setting the timer	64
	Delete timer	65
	Daily timer overview	65
	Set timer switching times	65
	AutoClean cleaning cycle	66
	Button layout	66
	Eco mode	67
	Daylight saving time	67
	Time zone	67
4.10	System	68
	Cooler	68
	Quality check (Dynamic Milk)	69
	Progress display	69
	Display and illumination	69
	Display brightness	70
	Reduce brightness automatically	70
	Touch calibration	70
	Display background	70
	Beverages: Font + colour	71
	Water filter	71
	Eco mode	72
	Temperature	72
	Grinding degree setting	73
	Brewing pressure display	73
	Portioner	73
	Bluetooth (optional)	73
	S-M-L Function	74
	Syrup (optional)	74
	Milk (optional)	74
	Nutritional information	75
	Cup detection (optional)	75
	Digital solutions	78
4.11	Language	78
4.12	Eco mode	79
	Eco mode display	79
4.13	USB	80
	Load recipes	80
	Load beverage symbols	80
	Save recipes	80
	Save recipes as pdf files	80
	Export counters	80
	HACCP export	81
	Data back-up	81
	Load data	81
	Load language	81
	Firmware update	81

Table of Contents

5	Care	82
5.1	Care safety instructions	82
5.2	Cleaning intervals overview	84
5.3	Cleaning programs	85
5.3.1	System cleaning	85
5.3.2	Milk system cleaning	89
5.3.3	Foamer rinsing	90
5.3.4	Foamer rinsing (Dynamic Milk)	90
5.3.5	Mixer rinsing	91
5.3.6	FFC filter change	91
5.4	Add cleaning agent (AutoClean)	92
	Coffee cleaning granulate	92
	Milk system cleaner	92
5.5	Manual cleaning	93
5.5.1	Clean the operating panel (CleanLock)	93
5.5.2	Clean the grounds container (grounds chute, optional)	94
5.5.3	Clean the drip tray	94
5.5.4	Clean the housing and the cup sensor	95
5.5.5	Clean the milk system manually	95
5.5.6	Clean the mixer	97
5.5.7	Clean the Auto Steam outlet	98
5.5.8	Clean the bean hopper	100
5.5.9	Clean the powder hopper	101
6	HACCP cleaning schedule	103
7	Maintenance and descaling	105
7.1	Maintenance	105
7.2	WMF Service	106
8	Messages and instructions	107
8.1	Messages for operation	107
8.2	Error messages and malfunctions	108
8.3	Errors without error message	110
9	Safety and warranty	113
9.1	Hazards to the coffee machine	113
9.2	Directives	114
9.3	Duties of the owner / operator	116
9.4	Warranty claims	117
Appendix: Technical data		118
Technical data for coffee machine		118
Appendix: Accessories and spare parts		122
Index		124

1 Safety



Misuse

- Failure to follow the safety instructions can result in death or serious injury.
 - > Follow all the safety instructions.
-

 **WARNING**

1.1 General safety instructions

Hazards to the operator

At WMF, safety is one of the most essential product features. The effectiveness of safety devices can only be ensured if the following points are observed:



- > Read the User Manual carefully prior to use.



- > Do not touch hot machine components.



- > Do not use the coffee machine if it is not working properly or if it is damaged.
- > Use the coffee machine only when it is completely assembled.

 **CAUTION**



> Built-in safety devices must never be altered.



> This device can be used by children of age 8 years or older while under continuous supervision, as well as



by persons with reduced physical, sensory, or mental capabilities or lack of experience or knowledge, once they have been instructed in the safe use of the machine and the risks associated with it.

> Children must not play with the device.

> Cleaning and user maintenance must not be performed by children.

 **CAUTION**

A coffee machine poses a potential for hazard when correctly used, despite the use of safety devices. Please observe the following instructions when using the coffee machine to prevent injury and health hazards:



Hazard to life due to electrical shock



WARNING



- The voltage inside the coffee machine is a hazard to life.
 - > Never open the housing.
 - > Never loosen the screws, and do not remove any housing parts.
 - > Avoid damage to the power cord. Do not kink or crush it.
 - > Never use a damaged power cord. A damaged power cord must be replaced by the manufacturer or a service representative in order to prevent a hazard.
 - > Never immerse the mains plug in water or other liquids. Never pour water or other liquids over the mains plug. Always keep the mains plug dry.
 - > Do not unplug the equipment's plug on the rear of the coffee machine until the power cord has been unplugged from the mains.
 - > The coffee machine must be disconnected from the power supply prior to maintenance and repair work. Pull out the plug to do so. The person performing the maintenance or repair must always be able to check, with a clear line of sight, that the power supply has been disconnected.



Burn hazard / scalding hazard

 **CAUTION**



- When dispensing beverages and steam, hot liquid comes out of the spouts. The adjacent surfaces and spouts become hot.



- Hot steam is produced by the SteamJet cup warmer. The cups and adjacent surfaces also get very hot.
 - Hot water and steam may escape from the outlets in the heating-up phase.
 - > When dispensing beverages and steam, do not reach beneath the spouts.
 - > Do not reach beneath the spouts during the heating-up phase.
 - > Do not touch the spouts immediately after dispensing.
 - > Always place an appropriate cup under the spout before dispensing a beverage.
-

**Risk of injury**

- Long hair could become caught in the grinder head and drawn into the coffee machine.
- > Always protect hair with a hairnet.
-

⚠ CAUTION**Pinching or crushing hazard / risk of injury**

- The coffee machine contains moving parts that can cause finger or hand injury.
 - Closing the operating panel can cause a crushing hazard.
- > Always switch off the coffee machine and unplug the mains plug before reaching into the coffee grinder or the opening of the brewing unit.
- > Carefully and gently close the operating panel.
- > Do not reach into the area of the moving spout.
-

⚠ CAUTION



Health hazard

- > Only use products that are suitable for consumption and for use with the coffee machine.
 - > The powder hopper, bean hopper, and the manual insert may only be filled with materials for the use intended.
-

 **CAUTION**



Slipping hazard



- Fluids can be discharged from the coffee machine if used improperly or if errors occur. These fluids can cause a slipping hazard.
 - Liquid may spill when the bottle of milk cleaning agent is replaced. This can cause a slipping hazard.
 - > Regularly check the coffee machine for leaks, and make sure no water is coming out.
 - > Replace the bottle of milk cleaning agent carefully. If liquid spills, wipe it up immediately.
-

 **CAUTION**



Health hazard / irritation and scalding hazard

 **CAUTION**



- During cleaning, hot cleaning solution and hot water run out of the combi spout and out of the hot water spout.
 - Hot liquids can irritate the skin, and the heat poses a scalding hazard.
 - The drip tray may contain hot liquids.
 - > Never reach under the spouts while cleaning.
 - > Ensure that no one ever drinks the cleaning solution.
 - > Be careful when moving the drip tray.
-



Health hazard

 **CAUTION**

- The milk system cleaner and the cleaning tablets are irritants.
 - > Follow the protective measures on the packaging of the cleaning agent.
 - > Only put in a cleaning tablet when an appropriate message is displayed.
-

1.2 Intended use



Misuse

- If the machine is used other than as intended, this could lead to a risk of injury.
 - > The coffee machine must only be used as intended.
-

WARNING

Guidelines

▷ *page 114*

Technical data

▷ *page 118*

- The WMF 5000 S+ is designed to dispense beverages made with coffee and/or milk and/or powder (such as Choc or Topping).
- The coffee beans, milk, topping, and chocolate powder products must be suitable for processing in a fully automated coffee machine. The products must not be processed after their expiration date.
- This device is intended for industrial and commercial use and should be operated by experts or trained users in stores, offices, restaurants, hotels, or similar places. It can also be used in a domestic environment.


Installation location

- The device can be used as a self-service device if it is supervised by trained personnel.
The machine must be set up so as to allow good visual access.
- The device must be placed and levelled on a horizontal, sturdy, water-resistant, and heatproof base.
- The device must not be cleaned using a water jet. The device must be installed where it is protected against water spray.
- The device must not be located on a surface that is sprayed or cleaned with a water hose, steam jets, steam cleaner, or similar devices.

Water supply

- 3/8 inch hose connector with water mains tap, and dirt filter with 0.08 mm mesh size, on-site. At least 0.2 MPa (2 bar) supply pressure at 2 l/min. Maximum 0.6 MPa (6 bar).

Important. If the customer's on-site flow pressure exceeds 0.6 MPa (6 bar), then a pressure reducer must absolutely be connected upstream and set to a maximum of 0.6 MPa (6 bar).



- Maximum inlet temperature 35 °C.
- The set of hoses provided with the new coffee machine, the permanent water connection kit, or the new water filter must be used. Do not use the old set of hoses.

Ambient temperature

- Ambient temperature +5 °C to a maximum of +35 °C

Usage

- The use of the device is subject to this User Manual. Any other use or use that goes beyond the aforementioned is considered incorrect use. The manufacturer shall not be liable for any damage resulting from this.
- **Under no circumstances may the WMF 5000 S+ be used to dispense and heat liquids other than coffee, hot water (beverages, cleaning) or milk (chilled, pasteurised, homogenised, UHT).**

Hygiene

- The coffee machine must be set up by the operator such that care and maintenance can be performed without hindrance.
- In office / floor kitchen areas or similar self-service set-ups, only staff instructed in operation of the coffee machine should supervise the coffee machine. Trained personnel should carry out care procedures and be available for questions regarding use.

1.3 Conditions for use and installation



Risk of fire and accidents

- > The conditions for use and installation listed in the "Technical Data" chapter must be met.
 - > Before inserting the device plug, ensure that the information on the rating plate matches the mains voltage for the installation.
-

WARNING

Technical data

▷ *page 118*

Follow the Safety chapter

▷ *starting on page 7*



Conditions for use and installation

- > Use the coffee machine only in places that will not freeze.
 - > If the coffee machine has been transported or stored at temperatures below 5 °C, then it must rest at room temperature for at least 5 hours before operating.
-

IMPORTANT

Technical data

▷ *starting on page 118*

Any necessary on-site preparatory work for electricity, water, and drainage connections at the customer's premises is to be arranged by the machine owner / operator. The work must be carried out by authorised installation technicians in compliance with general, country-specific and local regulations. The WMF Service engineers must only connect the coffee machine to existing prepared connection points. WMF Service is neither authorised nor responsible for carrying out any on-site installation work prior to connection.

The device must only be connected and commissioned by WMF Service.

2 Introduction

2.1 Parts of the coffee machine



"Ready to operate" display



Header bar

Function bar

- 1 Bean hopper (up to 2), lockable
- 2 Powder hopper (optional), lockable (Choc or topping, for example)
- 3 Manual insert / tablet insert
- 4 Fresh Filtered Coffee - FFC (optional)
- 5 Touch display for beverage buttons and settings
- 6 Hot water spout
- 7 Automatic cup detection (optional)
- 8 Grounds container
- 9 SteamJet cup warmer
- 10 Removable drip tray with drip grid
- 11 Steam outlet (optional)
- 12 Combi spout with integrated milk foamer
- 13 Operating panel
- 14 Side illumination
- 15 ON/OFF switch (Operating panel open)
- 16 Hopper lock

"Ready to operate" display

- 17 Eco mode
- 18 Menu pad (opens the main menu)
- 19 Beverage buttons
- 20 SteamJet pad
- 21 "Warm rinse" pad
- 22 Barista pad

The pads and buttons available on the display depend on the settings and the machine model.

The functions shown here are examples.

Software ▷ starting on page 36

User Manual Signs and Symbols



Personal injury safety instructions

If the safety instructions are not followed, this could lead to mild to severe injury in case of improper use.



WARNING

Follow the Safety chapter
▷ starting on page 7



Personal injury safety instructions

If the safety instructions are not followed, this could lead to mild injury in case of improper use.



CAUTION

Operation safety instructions
▷ page 24

Care safety instructions
▷ page 82

Follow the Safety chapter
▷ starting on page 7



Electrical shock



Hot steam



Pinching or
crushing hazard



Hot surfaces



Slipping hazard



Notice of property damage

- for the coffee machine
 - for the installation location
- > Always follow the User Manual.
-

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117

Technical data
▷ starting on page 118



Note / tip

- Instructions for safe use and tips for easier operation.
-

NOTE

TIP

Glossary

Term	Explanation
•	• Listings, selection options
*	* Individual steps
<i>Text in italics</i>	<i>Description of coffee machine state and/or explanations of automatic steps.</i>
Additions	Components of a recipe for a beverage, in addition to coffee, such as milk, milk foam, Choc and topping.
AutoClean	Fully automated cleaning system
Barista	Professional coffee server
Beverage dispensing	Dispensing coffee, hot water, or powder beverages
Capacity	For example: the capacity of the water filter in litres
Carbonate hardness	Quoted in °dKH. The water hardness is a measure of the calcium dissolved in the drinking water.
Chilled coffee	Reduces the dispensing temperature of freshly brewed coffee
Choc	Hot chocolate
Combi spout	Standard is double spout. Option available for single spout.
Cup detection	The sensor (optional) measures the cup height automatically. 3 different modes are available to choose from.
Decaf	Decaffeinated coffee
FFC	Fresh Filtered Coffee - FFC
Grounds chute	▷Grounds disposal through the counter, page 34
Main water supply tap	Water stop valve, angle valve
Milk system	Combi spout and milk hose
Mixer system	Complete module, mixer with portioner for powder beverages
Powder beverages	Such as Choc or Topping
Pre-infusion	Prior to brewing cycle, coffee is briefly infused in order to ensure a more intense release of its aromatic compounds.
Pressing	Automatic pressing of ground coffee prior to brewing cycle.
Rinsing	Intermediate cleaning
Self-service mode	Self-service customer operation

3 Operation

3.1 Operation safety instructions



Burn hazard / scalding hazard



- When dispensing beverages and steam, hot liquid comes out of the spouts. The adjacent surfaces and spouts become hot.



- Hot water and steam may escape from the outlets in the heating-up phase.
 - > When dispensing beverages and steam, do not reach beneath the spouts.
 - > Do not reach beneath the spouts during the heating-up phase.
 - > Do not touch the spouts immediately after dispensing.
 - > Always place an appropriate cup under the spout before dispensing a beverage.
-

 **CAUTION**

*Follow the Safety chapter
▷ starting on page 7*



Health hazard

- > Only use products that are suitable for consumption and for use with the coffee machine.
 - > The powder hopper, bean hopper, and the manual insert may only be filled with materials for the use intended.
-

 **CAUTION**

*Follow the Safety chapter
▷ starting on page 7*



Pinching or crushing hazard / risk of injury



- Be careful when fitting the FFC cover: risk of pinching.
- > Screw on the FFC cover carefully.

 **CAUTION**



Burn hazard / scalding hazard



- Hot liquid may escape while the "Fresh Filtered Coffee" is dispensing. The adjacent surfaces become hot.



- > Do not touch the FFC capsule while beverages are being dispensed.
- > Refrain from touching the FFC capsule immediately after dispensing.

 **CAUTION**

*Follow the Safety chapter
▷ starting on page 7*



Pinching or crushing hazard / risk of injury



- The coffee machine contains moving parts that can cause finger or hand injury.
- > Do not reach into the area of the moving spout.
- > Always switch off the coffee machine and unplug the mains plug before reaching into the coffee grinder or the opening of the brewing unit.

 **CAUTION**

3.2 Other documents

With syrup station option

- Follow the User Manual for the syrup station.
- Follow the Cleaning instructions for the syrup station.

3.3 Switch on the coffee machine

- * Slide the operating panel upward
The ON/OFF switch is on the right side, behind the operating panel.
- * Press the ON/OFF switch
*Coffee machine switches on and heats up.
An automatic warm rinsing starts.
When the coffee machine is ready to dispense beverages, the "Ready to operate" display appears.*

The coffee machine can be switched on and off using the timer.



PIN access control

▷ *PIN rights*
page 62

Set timer switching times

▷ *Timer*
page 64

3.4 Milk or milk foam

3.4.1 Connect up the milk

With WMF Cooler (Easy Milk, Dynamic Milk)

- * Remove the milk container from the cooler
- * Push the milk container lid back
- * Pour milk into the milk container
- * Place the lid back on the container
- * Insert the adapter on the milk hose into the connection in the milk container lid
- * Push the milk container back in carefully



Milk container

2-milk function

Make sure that the types of milk are connected to the right connection point on the machine. Make sure that milk 1 and milk 2 are not mixed up.




3.5 Beverage dispensing

Touching the beverage buttons triggers dispensing of the beverage selected.

- Lit up button = ready to dispense
- Unlit button / red triangle = not ready to dispense / button disabled

- * Place a cup of the appropriate size beneath the combi spout
- * Touch the desired beverage button



Beverage selection

*Button layout
▷ Operating options
page 56*

Cancel beverage

- * Touch the beverage button again

3.6 Fresh Filtered Coffee – FFC (optional)

Our new "Fresh Filtered Coffee" feature provides dispensing of filtered, freshly-brewed coffee. The freshly-brewed coffee is free from oil and sediment thanks to this additional filter system. Practically all coffee brews (Espresso or Café Crème) can be dispensed via this filter.



3.7 Pre-selection pads (optional)

Depending on the version, preselection buttons such as a "Second type of coffee" may be available on the display.

These are pre-selection pads that define the desired pre-selection prior to beverage selection using the beverage buttons.



Example:
Second type of coffee button
▷ page 40

3.8 Optional pads

There are optional pads, such as the Barista pad shown here, that can be shown on the function line of the display.

Another example is the S-M-L pad.

The S-M-L cup volumes need to be set for beverages in order for them to be available.

The cup volume "S" or "L" can then be selected prior to selecting a beverage, and then only those beverage buttons that have that size available will be illuminated.

M = size of the beverage set, no pre-selection


S = approx. 25% less than M

L = approx. 25% more than M

Activate and set up optional pads
▷ Operating options
page 53




Example:
Barista pad



Example:
S-M-L pad

3.9 Cup size adjustment

Free selection of the cup volume is optionally available. Depending on the setting, the cup volume can be adjusted in post-select mode after the beverage has been selected.



3.10 Hot water dispensing

* Place a cup of the appropriate size beneath the hot water spout

* Touch the hot water button

Dispensing occurs according to the dispensing option.



3.11 Steam dispensing



Burn hazard / scalding hazard



- When dispensing beverages and steam, hot liquid comes out of the spouts. The adjacent surfaces and spouts become hot.



- Hot water and steam may escape from the outlets in the heating-up phase.
 - > When dispensing beverages and steam, do not reach beneath the spouts.
 - > Do not reach beneath the spouts during the heating-up phase.
 - > Do not touch the spouts immediately after dispensing.
 - > Always place an appropriate cup under the spout before dispensing a beverage.



CAUTION

Follow the Safety chapter
▷ starting on page 7



Burn hazard / scalding hazard



- Milk and foam can boil over if the temperature is set to 90 °C.
 - > Fill jug to no more than half way.



CAUTION



- > Do not overheat milk when foaming, otherwise milk foam volume decreases.

TIP

3.11.1 Auto Steam (optional)

Milk is heated or foamed using the Auto Steam option. Milk can be foamed directly to the set milk foam quality by means of the steam button. Alternatively, a selection of up to 3 foam quality levels can be opened.

Potential milk foam qualities are:

- standard
- fine
- superfine

There is also an extra milk button with Auto Steam.

Heat milk or foam milk

✳ Fill a tall, narrow container with the desired milk quantity

Do not fill the jug above the halfway point, so that the milk will not run over when it foams.

✳ Immerse steam nozzle deep into the milk

✳ Briefly touch the desired Auto Steam button

Steam is discharged, depending on the Auto Steam button allocation.

Steam dispensing ends after reaching the set temperature, or when the Auto Steam button is touched again.

✳ Briefly press the steam button

Residue in the steam outlet tube is rinsed.

✳ Wipe the steam outlet with a damp cloth

3.11.2 Easy Steam (optional)

Beverages can be heated using the Easy Steam discharge.

Milk can be foamed by adding air manually.



Steam button



Button allocation

▷ Operating options
page 53

Change recipes
▷ Beverages
page 47

3.11.3 SteamJet cup warmer



Burn hazard / scalding hazard



- Hot steam is produced by the SteamJet cup warmer. The cups and adjacent surfaces also get very hot.



- > Use heat-resistant cups.
- > Always place a cup upside-down over the cup warmer before dispensing steam.
- > Do not touch the adjacent surfaces immediately after dispensing.
- > Do not touch the spouts immediately after dispensing.
- > Never use the SteamJet function without the drip grid in place or without the cup warmer insert.



CAUTION

Follow the Safety chapter
▷ starting on page 7
Clean drip tray daily
Care
▷ starting on page 82



Health hazard / hygiene


- The SteamJet function is intended for warming the cup and is not intended to be used for cleaning.
- > Always use freshly washed cups when warming cups.



CAUTION

Follow the Safety chapter
▷ starting on page 7

The SteamJet cup warmer can use steam to warm up to 2 cups at the same time.

- * Place a cup on the cup warmer with the opening facing downward
- * Touch the  pad

*Hot steam slowly flows into the cup from below.
The jet of steam stays on for the time set in the settings.*

- * Touch the SteamJet button again
The steam jet stops immediately.



SteamJet pad active / inactive
▷ Operating options
page 54

3.12 Height adjustment of the combi spout

Automatic height adjustment

The cup height is saved with the beverage for automatic height adjustment. Prior to beverage dispensing, the combi spout automatically moves to the optimal height.

Clearance height: up to 175 mm



Cup height
▷ page 51

Cup detection (optional)

Machines with optional cup detection can be operated in three different modes, depending on the setting.

- Presence detection
- Office - moves to cup height
- Size preselection

Cup detection
▷ System
page 75

3.13 Bean hopper / powder hopper lockable

- If possible, refill product hoppers in advance.
- Fill the hoppers no more than the amount needed for one day, in order to maintain the freshness of the products.



-
- ! • Foreign objects can damage the grinders. Such damage is not covered under the warranty.
 - > Ensure that no foreign objects land in the coffee bean hopper.
 - > Do not overfill the powder hopper.
 - > Do not press down and compact the powder.
-

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117

3.14 Manual insert, lockable

The manual insert is located in the centre of the coffee machine cover.

Manual insert is used

- When using additional coffee types, such as decaffeinated coffee
- For coffee sampling
- For inserting cleaning tablets



Tablet insert



- Add ground coffee or cleaning tablet only after the display message.
- Use only ground coffee in the manual insert.
- Do not use water-soluble powdered coffee.
- Do not use coffee that is ground too finely.

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117

Ground coffee prepared using the manual insert

- * Open manual insert lid
- * Insert ground coffee (maximum 19 g)
- * Close manual insert lid
- * Touch the desired beverage button



Manual insert

3.15 Grounds container

The grounds container receives the used coffee grounds. It has enough capacity to store coffee grounds from approx. 50 brewing cycles. The display shows a message as soon as the grounds container needs to be emptied.

Beverage dispensing is blocked for as long as the grounds container is removed.

- * Slide the combi spout upward
- * Remove grounds container
- * Empty and replace grounds container
- * Confirm process on the display



- Replacing without emptying will result in the coffee grounds container being overfilled. The coffee machine will be soiled. This may cause subsequent damage to the machine.
 - > Always empty the grounds container before replacing.
 - > If grounds container cannot be replaced, check chute for coffee residue and remove.



Clean the grounds container
▷ *Manual cleaning*
page 94

IMPORTANT

Follow the Warranty chapter
▷ *starting on page 117*

3.16 Grounds disposal through the counter (optional)

The coffee machine can be fitted with grounds disposal through the counter. In this case, both the grounds container and the coffee machine base have an opening that passes through the on-site counter on which the machine is placed. The spent coffee grounds are collected in a separate container under the counter.

Important

Clean grounds chute daily
▷ *Manual cleaning*
page 94

3.17 Drip tray



Scalding hazard



- The drip tray may contain hot liquids.
- > Be careful when moving the drip tray.
- > Replace carefully so that no water accidentally drips down.



CAUTION

Follow the Safety chapter

▷ starting on page 7

Clean drip tray daily

Care

▷ starting on page 82



3.18 Switch off the coffee machine



Take care to work hygienically

- Germs that are hazardous to health can grow in the coffee machine.
- > Perform daily cleaning before switching off the coffee machine.



CAUTION

Follow the Safety chapter

▷ starting on page 7

Clean the coffee machine as shown in the manual.

Care

▷ starting on page 82



Follow the manual

- If this is not followed, the liability is invalidated in the event of any resultant damage.

IMPORTANT

Follow the Warranty chapter

▷ starting on page 117

* Slide the operating panel upward

The ON/OFF switch is on the right side, behind the operating panel.

* Press the ON/OFF switch briefly (approx. 1 second)

The coffee machine then switches off.

* Disconnect mains plug

* Turn off main water supply tap



PIN access control

▷ PIN rights

page 62

4 Software



- When setting beverages, the same safety instructions apply as for operating the coffee machine.
- > Follow all operation safety instructions.


CAUTION

Operation safety instructions
 ▷ page 24

4.1 Overview

Ready to operate

page 38



Button layout
 ▷ Operating options
 page 56

The pads and buttons available on the display depend on the settings and the machine model.

Function bar "Ready to operate" display

page 38

	SteamJet cup warmer		Eco mode (active)
	Beverage size (S-M-L)		Warm rinsing
	Steam button		Barista (coffee strength)
	Second type of coffee (decaf)		Hot water
	Milk system refill		Cup size adjustment
	Nutritional information		Second milk type

Main menu functions

starting on page 41



Care
page 41



Beverages
page 44



Operating options
page 53



Information
page 60



Accounting
page 61



PIN rights
page 62



Timer
page 64



System
page 68



Language
page 78



Eco mode
page 79



USB
page 80

Menu control pads



Main menu / back



Confirm value / setting



PIN entry



Delete value / setting



Next / start



Preparation test



Load settings



Back



Save settings



Show keyboard

Messages on the display



Event and error message



Milk temperature display
(optional)

4.2 "Ready to operate" display

The display shown when "Ready to operate" depends on the individual settings and options of the coffee machine.

4.2.1 Beverage buttons

All beverage buttons that are ready to dispense are illuminated.

Depending on the button layout selected, a horizontal swipe on the display can bring up additional beverages. Beverage dispensing begins once the desired beverage button is touched.



Example: Cappuccino button

Button layout

*▷ Operating options
page 56*

4.2.2 Function bar

Hot water button

Hot water button for hot water dispensing.

Depending on the settings, touching this hot water button brings up a selection of three dispensing temperatures in two beverage sizes each.

A beverage button can also be assigned for hot water.



SteamJet pad

For heating cups.



SteamJet pad active / inactive

*▷ Operating options
page 54*

"Warm rinse" pad

※ Touch the "Warm rinse" pad

A rinse of the pipes with hot water starts. The water warms the brewing system and guarantees an optimum coffee temperature.

Recommended after a longer brewing pause, especially before dispensing a cup of espresso.



"Warm rinse" pad active / inactive
▷ Operating options
page 54

Nutritional information

Displays ingredients and nutritional information for each beverage.



Nutritional information
▷ Operating options
page 54

Cup size adjustment

For selecting beverage size for the next beverage.



Cup size adjustment
▷ Operating options
page 55

S-M-L pad

For pre-selecting beverage sizes. The beverages must be set up accordingly beforehand.



S-M-L
▷ Software
▷ System
page 74

Barista pad - coffee strength

	Display	Coffee strength
without touching	2 beans	normal, as per setting
touch 1x	3 beans	15% stronger than the setting *
touch 2x	1 bean	15% weaker than the setting *

* Maximum quantity of ground coffee 19 g per brewing cycle

The coffee strength will be altered for the next brewing cycle only.



Barista pad active / inactive
▷ Operating options
page 53

Milk system refill

For automatic "Milk system refill".



Milk system refill
▷ Operating options
page 56

Second type of coffee (decaf)

- * First of all, assign "decaffeinated" to a grinder in the machine data
- * Under operating options, select "Decaffeinated"
A bean symbol with a line through it is displayed in the function bar.
- * Tap the symbol before selecting a beverage
The beverage is then prepared from the beans in the decaffeinated coffee grinder.



Second type of coffee
▷ Operating options
page 57

Second milk type (optional)

There is an option to dispense a second type of milk. This could be skim milk or a soy drink, for example.




Second milk type
▷ Operating options
page 55

Steam button

The steam button is used to dispense hot steam for warming beverages.
Milk can be foamed by means of the steam button.



4.3 Care



Menu control pads

▷ Overview
page 36

Care


▷ starting on page 82

HACCP cleaning schedule

▷ starting on page 103

System cleaning

With switch off or without switch off the coffee machine after system cleaning.




System cleaning

▷ Care

starting on page 85

Mixer rinsing

Mixer rinsing is an intermediate cleaning of the mixer.




Mixer rinsing

▷ Care

page 91

Milk system cleaning

Milk system cleaning can be started separately. This makes sense if there are longer periods between dispensing milk beverages. The milk system cleaning program cleans the milk system.



Milk system cleaning

▷ Care

page 89

Intensive system cleaning (AutoClean)

This is a system cleaning that includes the milk hose. Can be used with the options "Switch off" or "Do not switch off" once system cleaning is complete. Recommended if operations are interrupted for longer than one day.

FFC filter change

Replace the filter after 100 brewing cycles/72 hours.

※ Touch **FFC filter change**

The display-guided instructions are launched.

※ Follow the instructions on the display

This pad can also be used to indicate how many more beverages can be dispensed with the current filter and when to next perform system cleaning with FFC.

Foamer rinsing

Foamer rinsing is an intermediate cleaning process for the milk foamer.

CleanLock

※ Touch **CleanLock**

A 15-second countdown starts.

The touch display can now be cleaned.

The touch display is activated again 15 seconds after the last time it was touched.



Intensive system cleaning



FFC filter change

FFC filter change

▷ Care
page 91



Foamer rinsing

Foamer rinsing

▷ Care
page 90




CleanLock

Clean the operating panel

▷ Care
page 93

Instructions

Animated instructions about the available cleaning programs and for installing and removing the mixer and combi spout for cleaning.



Instructions

Cleaning intervals overview
 ▷ Care
 page 84

Milk system refill (Dynamic Milk)

This function fills the milk system for dispensing cold beverages.

* Touch **Milk system refill**



Milk system refill

Settings



Settings

Switch-off rinsing

Options: • active • inactive

Default value: active

active When the coffee machine is switched off, the switch-off rinsing must be run if milk beverages have been dispensed since the last time the machine was cleaned.

Preparing the milk system after cleaning

Options: • active • inactive

Default value: inactive

active After the milk system cleaning cycle, the machine shuts down normally. If this function is activated, the user can replace and connect the milk container up to 15 minutes after cleaning. The coffee machine is then ready to run again.

4.4 Beverages



General information

Dispensing test

For many beverage settings, it is possible to start a dispensing test with the new settings before the recipe is saved.

- * Modify the settings as desired
- * Touch the "Dispensing test" pad
The beverage is dispensed using the newly changed values.
- * If the beverage is as desired, touch the Save symbol
The recipe is saved.



Example: Cappuccino button

Save recipes

The modified recipe is saved.



Load recipes

A saved recipe is loaded to a beverage button here.

- * Touch a beverage button
- * Touch the "Load recipes" pad
A submenu opens.
- * Mark the desired recipe
- * Touch the "Save recipes" pad
The beverage button is assigned to the newly selected recipe.



Cup volume, multiple brewing, and dispensing option



Cup volume

Set the desired filling volume. The recipe is adjusted accordingly.

100% indicates the previously saved value.

S-M-L Function

The S-M-L function is activated in the menu "System". The cup volume can also be set to a different general level for all beverages using the operating options. For individual beverages that deviate from the standard, the S-M-L quantity can be changed under cup volume.

Each size can also be individually set to active or inactive. Inactive means that the size no longer appears as a selection for the individual beverage.

Activate S-M-L and make a change for all beverages

▷ Software
▷ System
page 74

Optional pads

▷ Operation
page 28

Cup volume S-M-L

The recipes for the sizes S and L are generated.

M is as set.

Default value:

S = 25% less than the setting.

L = 25% more than the setting.

	S	M	L
	72	97	122
	73	98	123
	74	99	124
%	75	100	125
	76	101	126
	77	102	127
	78	103	128
	<input checked="" type="checkbox"/> S-active	<input checked="" type="checkbox"/> Active	<input checked="" type="checkbox"/> L-active

Change S-M-L for individual beverages

▷ Cup volume

Multiple brewing cycles

The beverage is brewed several times, as set. Up to 12 times the set quantity can be dispensed with one push of a button.

Available for beverages with coffee and with milk mixtures, as well as for hot water with the "metered" dispensing option.

Dispensing option

- **Start-Stop**

The dispensing runs until the set volume is reached. The dispensing can be stopped sooner by touching the button again.

- **Start-Stop-Freeflow**

A brief press of a button starts Start-Stop dispensing.

A longer press of the button, for more than 1 second, starts freeflow dispensing.

- **Freeflow**

The beverage or steam is output for as long as the button is pressed and held.

- **Metered**

The set volume is dispensed. The dispensing option is available for milk, foam, and hot water.

The dispensing option can be set for hot water, milk, and milk foam.

Change recipes



Menu control pads
 ▷ Overview
 page 36



Current recipe composition

The additions in the recipe are displayed here. The preparation order is from left to right. Additions that are above or below each other are processed at the same time. The software indicates whether desired options are not technically possible.

Inventory of factory additions

The additions that can be used for the recipe are shown here.
 ※ Touch the desired addition and then touch the desired position in the recipe composition again
The addition is immediately inserted at the desired position.

Delete addition

Delete a marked addition from the current recipe composition.



Change addition

※ Mark the addition and touch the symbol "Change addition"

The "Change addition" menu opens.

The setting options for the selected addition are displayed.

The saved and current data are displayed.



The current values



The values saved by Service



The factory values

Ground coffee quantity

Enter in grams (g)



Water quantity / milk quantity

Enter in millilitres (ml)



FFC

Set whether to direct the brewed coffee through the filter or not.



Chilled coffee

Set whether to direct the brewed coffee through the cooler to cool it down or not.



Dynamic Milk foam quality levels

Coffee machines with Dynamic Milk can use different milk foam quality levels for each beverage.

It is possible to combine several milk foam quality levels in one beverage.

- Compact** Firm milk foam. Recommended for cappuccinos with a brown edge and for beverages where the appearance of the milk foam is important, along with balanced milk flavour.
- Fluid** Very fine milk foam. Recommended for cappuccinos with balanced and very distinct milk flavour. Optimal blending of coffee and milk.
- Creamy** Milk foam with a shiny surface. Recommended for milk beverages with balanced milk flavour and a good blend of coffee and milk.
- Fluffy** Fluffy, light milk foam with a somewhat coarser bubble structure and balanced milk flavour.

Coffee quality

The quality levels influence the coffee brewing cycle. The higher the quality level, the more intensive the release of the flavour and aromatic substances in the coffee.



Quality levels


- 1 After pressing, space is provided for the ground coffee to swell.
- 2 After pressing, the coffee is brewed immediately.
- 3 After pressing, a pre-infusion occurs.
- 4 After pressing and a pre-infusion, wet pressing occurs.
- 5 Same as for Quality 4, but with stronger wet pressing.
- 6 Same as for Quality 5, but with stronger and longer wet pressing.
- 7 Same as for Quality 6, but with stronger and longer wet pressing.

Note.

If very finely ground coffee is used with a small amount of brewing water, a high quality level can cause a brew water flow error.

Select coffee grinder

A full portion of coffee to be ground corresponds to 10. The total amount can be produced cumulatively by different grinders. This means that a variety of individual recipes are possible.



Text, picture, and cup height



Menu control pads
▷ Overview
page 36

The "Detect cup" button is displayed only if "Presence detection" is active.
▷ Presence detection with cup sensor
▷ page 51

Text and picture

The beverage name and photo of a beverage button are adjusted here.

* Activate the keyboard by touching the keyboard pad

Load custom beverage pictures
▷ USB
page 80

Note

A note about the beverage can be saved here.

Set the cup height manually

The cup height for the beverage is selected using the setting wheel.

- * Use the setting wheel to adjust the height
- * On the right side, touch the desired cup symbol to be assigned to this height

The value is assigned to the cup symbol.

For size "S" and "L" beverages, the size must be selected prior to selecting the beverage button.

Presence detection using the cup sensor Cup detection (optional)

The "Detect presence" function causes the **Detect cup** button to be displayed.

- * Place a cup under the spout
- * Touch **Detect cup**

The cup is detected.

The setting for the detected cup height is saved and shown on the setting wheel on the display.

When set up this way, with active presence detection, the spout will move to the height saved for the beverage when the beverage is selected.

Size preselection with cup sensor

The sensor detects the cup height and enables the beverage if the detected height matches the saved value.

The size can be selected by the cup sensor only in "Size preselection" mode.

▷ page 76

Cup height tolerance

*▷ System ▷ Cup detection
page 75*

Use configured cup heights S-M-L

If this button is active, then the cup heights are set in the system menu.

If this function is active, the height can no longer be adjusted manually. The setting wheel is no longer displayed.

*S-M-L must be active. Make cup settings under
▷ System ▷ Cup detection
page 75*

Change buttons

The positions of two beverage buttons are swapped here.

- * Touch a beverage button
- * Touch the "Change buttons" pad
- * Touch the beverage button that is to be swapped



4.5 Operating options



Operating elements

Operating elements

SB mode (self-service)

For self-service mode, a few functions can be switched to be inactive.

These functions and their pads are not displayed in the inactive state.

Options: • active • inactive

Default value: inactive

SB mode active means that the following settings are set at the same time.

- Barista pad: inactive
- "Warm rinse" pad: inactive
- Nutritional information: active
- Menu pad: inactive
- SteamJet: inactive
- Error message: inactive
- Cup size adjustment: inactive
- Second milk type: inactive
- Language pre-selection: active
- Milk system refill: inactive
- Beverage pre-selection: inactive
- Cancel beverage: inactive

Barista pad

Options: • active • inactive

Default value: active

active The pad is displayed when ready to operate.

<i>Barista pad</i>	page 53
<i>"Warm rinse" pad</i>	page 54
<i>Nutritional information</i>	page 54
<i>Menu pad</i>	page 54
<i>SteamJet</i>	page 54
<i>Error message</i>	page 55
<i>Cup size adjustment</i>	page 55
<i>Second milk type</i>	page 55
<i>Language pre-selection</i>	page 56
<i>Milk system refill</i>	page 56
<i>Beverage pre-selection</i>	page 58
<i>Cancel beverage</i>	page 58

“Warm rinse” pad

Options: • active • inactive

Default value: active

active The pad is displayed when ready to operate.

Nutritional information

Displays ingredients and nutritional information for each beverage.

Enter nutritional information
▷ System
▷ Nutritional information
page 75

Options: • active • inactive

Default value: inactive

Menu pad

Options: • active • inactive

Default value: active

active The menu pad reacts immediately when the pad is touched.

inactive Touching the empty pad twice calls up the main menu.

SteamJet

Options: • active • inactive

Default value: inactive

active The pad is displayed when ready to operate.

Error message

The error is displayed in various colours in the header bar on the display.

Options: • active • inactive

Default value: active

active The errors are shown on the display as a text message.

Cup size adjustment

The open selection of cup volume can be activated in the operating options.

The cup volume can be adjusted to the cup size used prior to selecting the beverage.

Options: • active • inactive

Default value: inactive


Sliding the cup on the controller to the right increases the cup volume, and sliding left reduces it.

The cup volume is indicated in percent.

Controller in the centre 100 % as set

Controller all the way left 50 % less

Controller all the way right 50 % more



This function cannot be used at the same time as the active S-M-L preselection.

Second milk type (optional)

A second type of milk is activated here.

There is an option to dispense a second type of milk.

This could be skim milk or a soy drink, for example.

Options: • active • inactive

Default value: inactive

Language pre-selection

This setting determines whether languages and flags pre-selection can be set from the beverage settings. "Language pre-selection" can be activated here, or by selecting the "Self-service+Flags" button layout.

Options: • active • inactive

Default value: inactive

Button layout "Self-service+Flags"
▷ *Button layout*
page 56

Milk system refill

This function fills the milk system. "Milk system refill" can be activated here.

Options: • active • inactive


Default value: inactive

active The errors are shown on the display as a text message.

Milk system refill
▷ *Care*
page 43

Button layout

Various standard button layouts are saved and can be selected here.



PostSelection

Options: • active • inactive

Default value: inactive

active The type of coffee and the size of the beverage are requested after the beverage has been selected.

The names of the types of coffee and the sizes can be modified. (Type of coffee and S-M-L).

The displays and options will vary, depending on the model.

- Size 1, 2 and 3
- Portioner 1, 2, 3, and 4
- Milk type 1 and 2
- Cold beverages
- Syrup 1, 2, 3, and 4 (optional)

For self-service mode, a few functions can be switched to be inactive.

The functions and their pads are not displayed in the inactive state.



Options which are needed by the post-selection function are enabled in the System menu.

*System
▷ starting on page 68*

Caffeine-free

Options: • active • inactive

Default value: inactive

Decaf factor

The value for the Decaf factor is entered here.

Ground coffee quantity for Decaf (decaffeinated coffee) is set by percentage for the ground coffee quantity set in the recipe.

This setting applies to all coffee beverages with pre-selected "Decaf".

Setting range: -25% to 15%

Default value: 10%





For a Decaf factor of 15%, Café Crème is brewed with 15% more ground coffee, for example, when prepared using the Decaf function.

Beverage pre-selection

Options: • active • inactive

Default value: inactive

active Previously selected beverages are dispensed without an additional button touch. The header bar displays, "Beverage pre-selection active".

Cancel beverage

Options: • active • inactive

Default value: inactive

active Beverage dispensing can be interrupted by touching the beverage button again.

Milk foam selection

Options: • active • inactive

Default value: active

Milk foam selection is possible only with Auto Steam option.

Logo

Manufacturer's logo

Options: • active • inactive

Default value: active

active The manufacturer's logo is shown at the top right of the "Ready to operate" display.

Customer's logo

Options: • active • inactive

Default value: inactive

active When the option is set to "active" and a customer's logo has been downloaded, the customer's logo is shown at the centre of the header bar when "Ready to operate". When the vending devices are connected it shows the customer's logo. In this case, both logos cannot be displayed.

Load customer's logo

Insert the USB stick containing the customer's logo.
Load the customer's logo.

Size of customer's logo

The logo must not be greater than 80 pixels high.
Larger logos will be scaled to this size automatically.


4.6 Information

The info menu has the following selection options, as described below.



Last brewing cycle

Information about the last brewing cycle.



Timer

The weekly overview of the timer opens. All switch-on and switch-off times are displayed in this overview.



Service

Contact data for WMF Service.
Serial number of the coffee machine.




Care

The last cleaning and care actions that run via coffee machine programs are displayed here.



Water filter and descaling

Information on the remaining capacity of the water filter and the time of the next descaling.




Journal

Journal of events and errors during operation and cleaning of the coffee machine.



4.7 Accounting



Counters

The counters for the individual dispensed beverages and the totals of the beverages are displayed here. A journal can be read out via the USB port.

Accounting				
Counters				
Beverage	1	2	3	4
2 Espresso M...	2	2	2	2
Espresso	1	1	1	1

Standard setting

Counters 1 through 4 = continuous counters



The individual counters can be reset manually, independently of each other. (For example counter 1 = daily, counter 2 = weekly, etc.)

TIP

Vending machines

See vending machines User Manual.

External accounting

See the waiter accounting instructions.

Free of charge settings

The free settings are available, along with optional accounting units.


Free of charge settings

All free of charge

Options: • active • inactive

Default value: inactive

Beverage free of charge

Options: • active • inactive

Default value: inactive

Message display

When "All free of charge" is set to active, a text can be saved here. (e.g., "Free of charge") The text is displayed in the header bar.

Display beverage buttons

When "All free of charge" is set to active, a text for the beverage button can be saved here.

4.8 PIN rights

One PIN can be assigned for each of the areas listed below.

- Cleaning
- Setting
- Accounting



The PINs are hierarchical.


This means, for example: the settings PIN simultaneously grants all rights for the cleaning PIN, but not the rights for the accounting PIN.

If no PIN is assigned, then the area is accessible without a PIN. If a PIN has been assigned for a particular level, no access will be granted without a PIN.

Cleaning PIN









On entering the valid PIN, access granted to:

 Care



Settings PIN










On entering the valid PIN, access granted to:

 Care	 Timer
 Beverages	 System
 Operating options	 Language
 Accounting (without "delete")	 USB



Accounting PIN

On entering the valid PIN, access granted to:


 Care	 PIN
 Beverages	 Timer
 Operating options	 System
 Accounting (with "delete")	 Language
	 USB



The Accounting PIN can be used to change the other two PIN numbers. If you have forgotten the Accounting PIN, it can be reset only by our service department.

Re-enter PIN

Once a PIN has been assigned for access rights, the PIN number must be entered here in order to assign a new PIN.



4.9 Timer

Time / date

The current time of day and the date are set here.

Timer

The timer functions in general can be switched on and off here.

Options: • active • inactive



Default value: active

active The timer switching times are active.

inactive The timer switching times are not carried out.

Timer overview and setting the timer

Overview of all switch-on and switch-off times



The switching points can be changed only from the daily view.

Delete timer

To delete a previously highlighted switching time, touch the Delete symbol.



Daily timer overview

Switching between daily and weekly overview. The daily overview shows switching times for the current day.



Set timer switching times

The following functions can be switched by means of the timer.

- Button layout
- Eco mode
- ON/OFF timer
- AutoClean cleaning cycle



All changes to switching times take effect in the future only.

NOTE

- * Select desired timer option
- * Select individual day or days
- * Set timer switching times

The times are previously set for all selected days. After confirmation, a weekly overview is displayed with the switch time settings. The individual times can be modified in this weekly overview, as desired.


AutoClean cleaning cycle

Options: • active • inactive

Default value: active

active If "Active" is set for the AutoClean function, then cleaning times can be set up for AutoClean. This defines when the cleaning will start automatically.

Select whether the machine should shut down after cleaning, or whether to perform intensive system cleaning. Also set whether milk beverages will be enabled following the intensive system cleaning cycle.

-
-  > Set an on/off timer for the days of intended operation.
 - > Link these times to a cleaning cycle.

Example:

hours of operation Mo-Fr 8 AM – 6 PM.

- > Set the ON/OFF timer with cleaning for 7:30 AM – 6:30 PM.

We recommend setting up intensive system cleaning prior to breaks in operation that last longer than one day.

Button layout

Options: • active • inactive

Default value: inactive

active Button layouts can be assigned automatically via the timer.


TIP

Follow safety instructions for customer care

▷ *page 82*

Safety and warranty

▷ *page 117*





Eco mode

This setting determines whether Eco mode timers can be adjusted.

Options: • active • inactive

Default value: inactive



Eco mode

Daylight saving time

Set whether to switch to daylight saving time automatically here.

This menu is displayed only if no telemetry module is installed.

Options: • active • inactive



Default value: inactive



Daylight saving time

Time zone

The time zone can be set here.



Time zone

4.10 System



Cooler



Milk storage temperature

Enter the milk storage temperature here.
For example, <10 °C when using Cup&Cool.



*Possible with optional Cup&Cool
with temperature monitoring.*

Empty message

(Cooler with low-level warning function is required)

This setting determines whether a milk empty message will be shown.

The empty message can be coupled with a beverage lockout. This is especially important for self-service mode, so that paid beverages are guaranteed to be dispensed completely.

Temperature sensor

(Cooler with sensor required)

The milk temperature is measured.

Quality check (Dynamic Milk)

External influences can cause changes to the milk temperature, milk foam volume, and milk foam quality in the milk system.

The "Quality check" menu can be used to reset the settings to their base values.

- * Fill the blue cleaning container with cold water
- * Connect the milk hose
- * Place a measuring cup with 500 ml capacity under the spout
- * Start the calibration
- * As soon as the measuring cup has been filled with 500 ml (+/- 20 ml), stop the calibration



Quality check

Progress display

Options: Line, circle, off

Default value: Line



Progress display

Display and illumination

Illumination

The illumination colour is set here.

Set the desired colour from the colour circle above the triangle. The colour can also be defined and set by means of RGB values.

There are also the following options:

- Slow colour change
- Standard colour change
- Quick colour change
- Off

The current setting is displayed immediately.



Display and illumination



Illumination when "Ready to operate"

- Standard colour side

Event display (message)

Options: • active • inactive

For example, "Beans empty" message.

Default value:  inactive

active The illumination during a message can be adjusted.

Illumination for messages (event)


- Event colour side

Display brightness

The brightness of the display is adjusted here.

Reduce brightness automatically

Options: • active • inactive

Default value:  active

active If "Reduce brightness" is set to "active", then the display brightness is reduced automatically 5 minutes after the last beverage is dispensed. If the display brightness has been dimmed, the display returns to the selected brightness level when it is first touched. The second time a beverage button is touched, the corresponding beverage is dispensed.

Touch calibration

Recalibrate the touch display.

Display background

The colour design for the touch display can be set here.

Beverages: Font + colour

This setting determines whether the font size and colour are allowed to be changed.

Options: • active • inactive

Default value: inactive

Water filter

Options: • active • inactive

Default value: inactive

active Water filter is fitted. Capacity and water hardness are queried.



Water filter

Note

We recommend using a water filter. Your WMF service partner will be happy to advise you on the right water filter to use.

Measured carbonate hardness

Enter the measured water hardness in °dKH here.
The carbonate hardness test is supplied with the accessories.



If the coffee machine is run with the wrong water hardness setting, this can lead to severe lime build up and thus to leaking valves.
No liability is assumed for any resulting damage.

NOTE

Determine the water hardness

✳ Request drinking water hardness reading from water supplier, or determine using WMF carbonate hardness test (complete with instructions) in the accessories

Measured total hardness

Enter the measured total hardness.

Filter capacity

Enter the filter capacity in litres here.

Eco mode

The Eco mode can be activated here.

Options: • active • inactive

Default value: inactive


Switch off

Options: never, 30 min/60 min/90 min/120 min/
150 min/180 min

Default value: never

Temperature

The boiler water temperature is set here.
(coffee brewing water temperature)



▷ Eco mode
page 79



Grinding degree setting

The grinding degree can be adjusted from the display.

- Grinding degree grinder 1
- Grinding degree grinder 2

Lower number -> finer grinding degree

Higher number -> more coarse grinding degree

The setting has intervals of 0.25. Up to half a grinding degree can be adjusted in each step. The grinder must be run between each adjustment.

Only for trained personnel and service.



Grinding degree setting

Brewing pressure display

The brewing pressure display can be activated here.

Options: • active • inactive

Default value: inactive



Brewing pressure display

Portioner

The names of the beans and powders used can be saved here.

Espresso or Café Crème are the default options available.



Portioner

Applies to machines with two grinders and one powder hopper.

Bluetooth (optional)

The optional WMF Bluetooth stick is required for this function.

Options: • active • inactive

Default value: inactive

- * Set Bluetooth to active here
- * Open the operating panel
- * Insert the WMF Bluetooth stick on the back side of the operating panel
- * Switch the coffee machine off and on again



Bluetooth

S-M-L Function

Activate the S-M-L function here.
Change symbols and texts here.
Beverage sizes can be changed based on the standard size (M).


Options: • active • inactive

Default value: inactive



Small

Standard modification factor for beverage sizes for S-recipes that are newly activated.
Default value: 75%



Large

Standard modification factor for beverage sizes for L-recipes that are newly activated.
Default value: 125%

Cup volume S-M-L
▷ Software
▷ Beverages
page 45

Tip

Beverage sizes S-M-L can also be defined in the recipe and are then available directly as a beverage button.

Syrup (optional)

Assign names and symbols to syrups here.
Activate the available metered quantities (single, double, big).



Detailed setting capability for the syrup station
▷ User Manual for Syrup station


Milk (optional)

Assign names and symbols to milk 1 and milk 2 here.



Nutritional information

Detailed information on about nutritional values and ingredients can be captured here for each grinder, portioner, milk, and milk foam.
An overview is available.



Nutritional information

Cup detection (optional)

The cup sensor detects whether there is a receptacle beneath the spout and determines its height.



Cup detection

Correction of spout position

Setting range: -20 mm to +60 mm
Minus → Smaller distance from cup
Plus → Greater distance from cup
Steps: 5 mm
Standard: 10 to 15 mm distance

Cup height tolerance

The tolerance for cup height is set here for beverages with inactive S-M-L.

The height for a recipe is set in the beverage menu.
The tolerance set here determines how precise this height must be in order to enable the beverage.
The required tolerance is thus entered here.

Setting range: 0 mm to ± 30 mm
Steps: approx. 7.5 mm

Mode

Choose between four different modes.

Off

The function is deactivated.

Presence detection

The cup sensor detects whether there is a receptacle beneath the spout. Once a beverage is selected, the spout automatically moves to the pre-configured height for the selected beverage.

Cup height adjustment

▷ Software

▷ Beverages

page 51

Office – moves to cup height

The cup sensor detects whether there is a receptacle beneath the spout and determines its height. The spout then moves to a preset distance from the top of the cup.

Size preselection

The cup sensor detects whether there is a receptacle beneath the spout and determines its height. Based on this value, matching beverages are shown on the display. If S-M-L pre-selection is active, the sensor performs this pre-selection.

Size setting S-M-L

In "Size preselection" mode

The cup currently under the spout is shown as a symbol on the display.


The smallest and largest cup size setting for each beverage size is displayed.



The two horizontal lines are the boundaries between the beverage sizes.

The arrow symbols can be used to move these lines.


Delete cup sizes

- * Touch 
- * Select a desired size or "All size"

The selection is deleted.

The cup size is deleted.

Add cup size

- * Place the new size cup under the spout
- * Assign the desired S-M-L size
- * Touch 

Change the size designations for beverages

▷ System

▷ S-M-L

page 74

Customer cups

This option provides the ability for the customer to use its own reusable cups in self-service mode.

When the "Customer cups" option is activated, the starting screen changes.

Here, in the cup detection, the starting screen can be set as desired.



Starting screen with customer cups

Using "Own cup"

- * Touch **Own cup**
- The beverage selection is displayed.*
- * Select desired beverage
- The desired beverage size is requested.*
- * Select the correct beverage size
- The beverage is dispensed.*


Using "Operator cup"

- * Touch **Operator cup**
- The beverage selection is displayed.*
- * Select desired beverage
- The cup sensor automatically detects the size of the cup under the spout and the beverage is dispensed according to the S-M-L settings.*



Beverage size preselection

Digital solutions


Digital solutions

Remote actions

Media packages that are not installed, but were sent via WMF Coffee Connect and not directly installed, can be implemented after the fact here.

Smart Remote

The WMF Service department can activate Smart Remote. This function can then be activated here.

4.11 Language

The language used in the display is set here.
The available languages are displayed in English.



4.12 Eco mode

If Eco mode is set to active, the steam boiler temperature is reduced 10 minutes after the last beverage is dispensed.

The beverage buttons remain lit.

If a beverage with a milk component is to be dispensed when the temperature is reduced, the coffee machine needs approx. 15 seconds to heat up.

Beverage dispensing starts after the machine has heated up.



▷ Eco mode
page 72

Eco mode

Options: • On • Off • Timer

Default value: On Off



The Eco mode can be activated here.

Eco mode display

The Eco mode symbol is displayed on the in the header bar of the "Ready to operate" display.

There are two states.

Eco mode "active"

The coffee machine is currently in the reduce phase.



Eco mode "ready"

Eco mode is based on idle time, 10 minutes after the latest beverage has been dispensed.



Immediate start

When Eco mode is set to "active", the Eco mode symbol is shown on the "Ready to operate" display.



Touching the symbol activates Eco mode immediately. The symbol changes to "active."

4.13 USB


Data exchange is possible via the USB connection. As long as the USB stick is inserted, the functions will be active.

The USB connection is at the top left on the reverse side of the operating panel, behind a cover.




Load recipes

The recipes stored on the USB stick are loaded to the coffee machine here.




Load beverage symbols

Load photos or beverage symbols from USB stick.




Save recipes

Current recipes are exported from the coffee machine to the USB stick here.



Save recipes as pdf files

The active recipes, all customer recipes, or all factory recipes can be exported as PDF files.



Export counters

Current counter levels are exported from the coffee machine to the USB stick here.




HACCP export

The cleaning cycles performed are recorded and are exported to the USB stick here as evidence for HACCP.


HACCP export


Data back-up

Data settings, such as machine data, beverage data, etc. are saved to the USB stick here.


Data back-up

Load data

Data settings, such as machine data, beverage data, etc. are loaded here from the USB stick to the coffee machine.
(Can be protected by a PIN.)


Load data


Load language

If available, another display language can be loaded to the coffee machine from the USB stick here.


Load language

Firmware update

For Service only.


Firmware update

5 Care

5.1 Care safety instructions

Regular cleaning is essential in order to ensure problem-free operation of the coffee machine and to ensure optimum coffee quality.



Health hazard / hygiene

- Milk is very sensitive. Germs that can pose a health hazard can build up in the milk system.
 - > Clean the milk system daily.
 - > Replace the milk hose at regular intervals.
 - > Change the mixer hose at regular intervals.
 - > Follow all hygiene instructions.
 - > Follow the HACCP cleaning schedule.
-

**CAUTION**

Follow the Safety chapter
▷ starting on page 7



Health hazard / hygiene

- Germs can multiply in a coffee machine that is not in use.
 - > Prior to and after every instance that the machine is shut off for several days, perform all cleanings.
-

**CAUTION**

Follow the Safety chapter
▷ starting on page 7



Health hazard / hygiene

- All cleaning agents are perfectly tuned to the cleaning programs.
 - > Use only WMF cleaning agent.
-

**CAUTION**

Follow the Safety chapter
▷ starting on page 7



Health hazard / irritation and scalding hazard



- Hot cleaning fluid and hot water runs out of the combi spout when cleaning. The adjacent surfaces and spouts become hot.
- Hot liquids can irritate the skin, and the heat poses a scalding hazard.
 - > Never reach under the spouts while cleaning.
 - > Make sure that persons who have not been instructed, and especially children, stay away from the coffee machine while it is cleaning.
 - > Always lock out the touch display with "CleanLock" before cleaning.
 - > Ensure that no one ever drinks the cleaning solution.

CAUTION

Follow the Safety chapter
▷ starting on page 7



Dynamic Milk

If no beverage with a milk component has been dispensed for 119 minutes, an automatic milk system rinse is started and the system is filled with fresh milk.

NOTE



Note

- The next time the coffee machine is switched on, fill up the milk again to complete the cleaning program.

NOTE

5.2 Cleaning intervals overview

Care						
Daily	Weekly	Regularly	Automatic			Instructions
Cleaning programs				▷ starting on page 85		
x				System cleaning (Easy Milk / Dynamic Milk / AutoClean)		0
	x			Intensive system cleaning (AutoClean)		0
x				Rapid rinsing (AutoClean)		
x				Milk system cleaning		0
x			x	Foamer rinsing		0
x				Mixer rinsing *		0
		x	x	FFC filter change *		0
Manual cleaning						
x				Clean the operating panel (CleanLock)		0
x				Clean the grounds container		
x				Clean the drip tray		0
x				Clean the housing and the cup sensor		
	x			Clean the milk system manually (Easy Milk)		
	x			Clean the milk system manually (Dynamic Milk)		
(x)	x			Clean the mixer *		0
x	x			Clean the steam outlet		0
		x		Clean the bean hopper		
		x		Clean the powder hopper *		



▷ page 91

▷ page 93

▷ page 94

▷ page 94

▷ page 95

▷ page 95

▷ page 97

▷ page 97

▷ page 98

▷ page 100

▷ page 101

Daily = Daily, at least once per day, and as needed

Weekly = Weekly cleaning

Regularly = Regularly as needed

Automatic = Automatic processing

(x) = Daily for severe soiling

* = Optional (depending on the model)

Instructions = Instructions available in the menu ▷ "Software" ▷ "Care"

5.3 Cleaning programs

5.3.1 System cleaning

System cleaning is an automatic cleaning program and consists of several segments. The coffee, milk, and powder systems are cleaned depending on how much they have been used. This includes milk system cleaning, mixer rinsing, and the use of two different WMF cleaning tablets for the coffee and milk systems. The optional functions FFC and Chilled Coffee are also cleaned as needed as part of the system cleaning cycle.

Instructions as animation

▷ Main menu

▷ Care

▷ Instructions

▷ Syrup station cleaning instructions



Health hazard / irritation and scalding hazard



- During cleaning, hot cleaning solution and hot water run out of the combi spout and out of the hot water spout.
- Hot liquids can irritate the skin, and the heat poses a scalding hazard.
- > Never reach under the spouts while cleaning.
- > Ensure that no one ever drinks the cleaning solution.



CAUTION

Follow the Safety chapter

▷ starting on page 7



The cleaning program provides a step-by-step guide through the system cleaning on the display.
Follow the messages.

NOTE

System cleaning (Easy Milk / Dynamic Milk)



Health hazard / scalding hazard

- During the cleaning cycle, hot cleaning solution flows into the container.
 - > Carefully empty the cleaning container after cleaning.
-



Never place the cleaning container in the cooler while it is hot, as this can damage the cooler.

For system cleaning for coffee machines with Easy Milk / Dynamic Milk, the special blue cleaning container is required for cleaning.

Start

- * Start the Care menu
- * Touch **System cleaning**
- * Follow the information on the display

System cleaning cycle (AutoClean)

The daily system cleaning cycle runs fully automatically with AutoClean. The blue cleaning container is no longer needed.

The machine dispensed the required amount of cleaning agent fully automatically.

- * Start the Care menu
- * Touch **System cleaning**
- * Follow the information on the display

The system cleaning cycle can optionally be set up from the Timer menu.



CAUTION

Follow the Safety chapter
▷ starting on page 7

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117



AutoClean
▷ Software
▷ Timer
page 66

Intensive system cleaning (AutoClean)



Health hazard / scalding hazard

- If the Plug&Clean Adapter is pulled out while the cleaning or rinsing cycle is running, hot water or steam may escape.
- > Never pull out the Plug&Clean Adapter while the cleaning or rapid rinse cycle is running.

Start

Once a week, or prior to shutting down operations for longer than one day, an intensive system cleaning must be performed.

- * Start the Care menu
- * Touch **Intensive system cleaning**
- * Follow the information on the display
- * Remove the milk hose from the container
- * Connect the milk hose to the Plug&Clean socket of the machine

The machine dispensed the required amount of cleaning agent fully automatically.

The intensive system cleaning cycle can optionally be set up from the Timer menu.



Check to make sure that the Plug&Clean adapter and the milk hose are seated correctly.



CAUTION

Follow the Safety chapter
▷ starting on page 7



NOTE

Follow the Safety chapter
▷ starting on page 7

Follow the Warranty chapter
▷ starting on page 117

Rapid rinsing (AutoClean)



Health hazard / scalding hazard

- If the Plug&Clean Adapter is pulled out while the cleaning or rinsing cycle is running, hot water or steam may escape.
 - > Never pull out the Plug&Clean Adapter while the cleaning or rapid rinse cycle is running.
-

Once a day, the milk hose must be rinsed using the rapid rinse function.

- ※ Remove the milk hose from the container
- ※ Connect the milk hose to the Plug&Clean socket of the machine

The rapid rinsing cycle starts automatically once the Plug&Clean adapter is locked.

The LED on the Plug&Clean socket flashes as soon as the rapid rinsing cycle is complete.



- When connecting a new milk container, always perform a rapid rinse.
Duration: 1–2 minutes
-



- Check to make sure that the Plug&Clean adapter and the milk hose are seated correctly.
-



CAUTION

Follow the Safety chapter
▷ starting on page 7



TIP

NOTE

Follow the Safety chapter
▷ starting on page 7

Follow the Warranty chapter
▷ starting on page 117

5.3.2 Milk system cleaning



Health hazard / scalding hazard

- During rinsing, hot rinsing water flows out of the combi spout.
- > Never reach under the spouts while rinsing.

Milk system cleaning can be started separately. This makes sense if there are longer periods between dispensing milk beverages.

The milk system cleaning program cleans the milk system.

For milk system cleaning for coffee machines with Easy Milk / Dynamic Milk, the special blue cleaning container is required for cleaning.

A special cleaning tablet must be used.

- * Start the Care menu
- * Touch **Milk system cleaning**
- * Follow the information on the display



CAUTION

Follow the Safety chapter
▷ starting on page 7

Instructions as animation
▷ Main menu
▷ Care
▷ Instructions



5.3.3 Foamer rinsing



Health hazard / scalding hazard

- During rinsing, hot rinsing water flows out of the combi spout.
 - > Never reach under the spouts while rinsing.
-

**CAUTION**

*Follow the Safety chapter
> starting on page 7*

For coffee machines with Easy Milk, there is a foamer rinsing that can be started when needed. The foamer rinsing can also take place automatically. This is started automatically after 3 minutes since the last milk beverage was dispensed. An acoustic warning signal sounds before foamer rinsing starts automatically. When the foamer rinsing is activated, there must be no previously dispensed beverages located beneath the combi spout.

- * Start the Care menu
- * Touch **Foamer rinsing**
- * Follow the information on the display

*Instructions as animation
> Main menu
> Care
> Instructions*

5.3.4 Foamer rinsing (Dynamic Milk)

For coffee machines with Dynamic Milk, the foamer is rinsed automatically every 2 hours.

5.3.5 Mixer rinsing



Health hazard / scalding hazard

- During rinsing, hot rinsing water flows out of the combi spout.
- > Never reach under the spouts while rinsing.

Mixer rinsing can be started separately.

- * Start the Care menu
- * Touch **Mixer rinsing**
- * Follow the information on the display

CAUTION

Follow the Safety chapter
▷ starting on page 7

Instructions as animation
▷ Main menu
▷ Care
▷ Instructions

5.3.6 FFC filter change



Health hazard / scalding hazard

- > The filter capsule remains hot immediately after coffee is dispensed via the filter.
- > Allow the filter capsule to cool slightly before replacing.

CAUTION

Follow the Safety chapter
▷ starting on page 7

Replace the filter after 100 brewing cycles/72 hours.

- * Start the Care menu
 - * Touch **FFC filter change**
- The display-guided instructions are launched.*

- * Follow the instructions on the display
- This menu shows how many more drinks can be dispensed via this filter and how many hours remain before filter replacement is due.

5.4 Add cleaning agent (AutoClean)

Coffee cleaning granulate

- * Open manual insert lid
- * Flip the green flap forward
- * Remove the granulate dispenser from the machine and turn it upside down
- * Open the dispenser by turning it
- * Remove the empty cleaning granulate container and insert a new one



Milk system cleaner

- * Unscrew the cleaning adapter from the empty bottle of milk system cleaner
- * Connect a new bottle of WMF milk system cleaner



5.5 Manual cleaning

Order numbers for the WMF care program
▷ Accessories and spare parts page 122

5.5.1 Clean the operating panel (CleanLock)

* Touch **CleanLock**

A 15-second countdown starts.

The touch display can now be cleaned.

The touch display is activated again 15 seconds after the last time it was touched.



Scalding hazard

- If a beverage is initiated accidentally, there is a hazard of being injured.
 - > Always lock out the touch display with "CleanLock" before cleaning.



CAUTION

Follow the Safety chapter
▷ starting on page 7



- There is a risk of causing scratches or scoring.
 - > Clean the display with a clean, damp cloth. Do not use any cleaners or implements.
 - > Use soft cloths for cleaning.
 - > We recommend a damp microfiber cloth.

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117

5.5.2 Clean the grounds container (grounds chute, optional)

- * Empty grounds container and rinse under running drinking water
- * Clean with a clean, damp cloth
- * Dry the grounds container and replace it



- > On coffee machines with grounds disposal through the counter, the grounds chute must be cleaned daily.
 - > Never use force. Danger of breakage.
-

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117

5.5.3 Clean the drip tray



Scalding hazard



- The drip tray may contain hot liquids.
 - If the drip tray is not properly engaged, such as after cleaning, there is a burn hazard due to hot liquids.
 - > Be careful when moving the drip tray.
 - > Replace carefully so that no water accidentally drips down.
 - > Always make sure the drip tray is seated correctly.
-

CAUTION

Follow the Safety chapter
▷ starting on page 7

- * Lift up the front of the drip tray slightly and remove it
- * Clean drip tray thoroughly
- * Rinse the drip tray with clear drinking water
- * Dry off the drip tray and replace it



Instructions
▷ Software ▷ Care
page 43

With optional syrup station
▷ Syrup station cleaning
instructions

5.5.4 Clean the housing and the cup sensor



- There is a risk of causing scratches or scoring.
- > Do not clean with scouring powders or the like.
- > Use only very mild cleaning agents.
- > Do not use any severely alkaline, alcoholic, or degreasing cleaning agents.
- > Use soft cloths for cleaning.
- > We recommend a damp microfiber cloth.

For cleaning metal cover parts (matte surface) we recommend WMF Purargan® cleaner.

- * Switch off the coffee machine using the ON/OFF switch
- * Allow the coffee machine to cool before cleaning
- * Once the coffee machine has cooled down, clean the housing with a damp cloth
- * Wipe dry with a fine cloth
- * Clean the sensor with a clean, damp cloth

5.5.5 Clean the milk system manually

Clean the milk system manually (Easy Milk)



Scalding hazard

- If a beverage is initiated accidentally, there is a hazard of being injured.
- > Always switch off the coffee machine prior to cleaning.
- > Disconnect mains plug.

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117

Note

Durability can be compromised with alkaline cleaning agents, solvents such as acetone, carbon, carbon tetrachloride, paint thinner, or alcohol compounds >5%, ammonia, degreasing flushing agents, and strong spray cleaners for glass are also not suitable.

Clean the display with a clean, damp cloth. Do not use any cleaners or implements.

CAUTION

Follow the Safety chapter
▷ starting on page 7

Instructions as animation
▷ Main menu
▷ Care
▷ Instructions



Health hazard

- In case of eye contact, the WMF milk system cleaner can cause severe eye injury.
- > Ensure that the milk system cleaner never makes contact with the eyes of a person or animal.

CAUTION

Follow the Safety chapter
▷ starting on page 7



- > Before the milk system is cleaned manually, a system cleaning cycle must be performed. The system cleaning removes milk residue from the system.

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117

- * Pull forward the lever behind the combi spout
- * Remove combi spout
- * Remove the milk hose and the mixer hose ⁽¹⁾
- * Mix 5 ml of WMF special cleaner or a special cleaning tablet with 500 ml of warm drinking water
- * Dismantle combi spout
- * Place all parts of combi spout in the cleaning solution (3 parts)

All parts must be completely immersed in the cleaning solution.

- * After 5 hours, clean all parts thoroughly with a brush
- * Rinse all parts of the combi spout very thoroughly with clear drinking water
- * Thoroughly rinse the milk hose and the mixer hose ⁽¹⁾
- * Attach the milk hose and the mixer hose ⁽¹⁾
- * Reassemble combi spout
- * Replace combi spout

⁽¹⁾ The mixer hose is included only for coffee machines with a mixer.



Clean the combi spout manually (Dynamic Milk)



For coffee machines with Dynamic Milk, the foamer must not be removed.

Regularly clean the outside of the combi spout with a damp cloth and clean the dispensing openings with the appropriate brushes.

Clean the Plug&Clean socket (AutoClean)

Clean the Plug&Clean socket with a brush when needed.

5.5.6 Clean the mixer

Clean more frequently depending on the powder used.



Scalding hazard

- If the mixer hose is not firmly attached, hot water or hot powder beverage can be discharged inadvertently.
- > Always install the mixer hose firmly.

- * Slide the operating panel upward
- * Pull the mixer hose off of the combi spout and use the handle to move the mixer bowl upward

The propeller for the mixer is now visible.

Daily

- * Remove the mixer bowl
- * Disassemble the mixer bowl into its four component parts
- * Thoroughly clean the parts under running drinking water

When needed (weekly)

- * Mix 5 ml of WMF special cleaner or a special cleaning tablet with 500 ml of warm drinking water

IMPORTANT

Follow the Warranty chapter
▷ starting on page 117

CAUTION


Follow the Safety chapter
▷ starting on page 7

Instructions
▷ Main menu
▷ Care
▷ Instructions



- * Immerse all four parts in the cleaning solution at least for 4 hours
- * After 4 hours, thoroughly rinse under running drinking water again
- * Remove the powder hopper and clean the loading chute to the mixer bowl with a cloth or brush

- * Allow all parts to dry completely [1]

 On re-assembly, all openings must face in the same direction.

- * Insert the mixer wheel [2] as shown in the illustration

The green side should be visible after insertion.

- * Attach mixer hose on the mixer bowl
- * Replace mixer bowl until it engages in the lock
- * Attach mixer hose on the combi spout



5.5.7 Clean the Auto Steam outlet

Burn hazard / scalding hazard

- When dispensing beverages and steam, hot liquid comes out of the spouts. The adjacent surfaces and spouts become hot.
- Hot water and steam may escape from the outlets in the heating-up phase.
 - > When dispensing beverages and steam, do not reach beneath the spouts.
 - > Do not reach beneath the spouts during the heating-up phase.
 - > Do not touch the spouts immediately after dispensing.
 - > Always place a suitable cup under the spout when dispensing.

 **CAUTION**

Instructions

▷ Main menu

▷ Care

▷ Instructions

Daily

- * Mix 5 ml of WMF special cleaner or a special cleaning tablet with 500 ml of warm drinking water
- * Immerse steam nozzle in the cleaning solution and touch the steam button or an Auto Steam button

Soak time: 30 minutes

- * Clean with a brush
- * Rinse thoroughly with water
- * Touch the steam button

The steam clears the holes of the steam nozzle of milk residue, and removes cleaner residue.

**Weekly**

- * Unscrew the steam nozzle
- * Immerse steam nozzle in the cleaning solution for at least 5 hours
- * Clean with a brush
- * Rinse thoroughly with clean water
- * Screw the steam nozzle onto the Auto Steam spout
- * Immerse steam nozzle in a jug with clear water
- * Briefly touch an Auto Steam button
- * Wipe the steam outlet with a damp cloth



5.5.8 Clean the bean hopper

The bean hoppers should be cleaned when needed and at regular intervals. Recommendation: monthly.



Risk of injury

- Long hair could become caught in the grinder head and drawn into the coffee machine.
 - > Always protect hair with a hairnet.
-

 **CAUTION**



Pinching or crushing hazard / risk of injury



- The coffee machine contains moving parts that can cause finger or hand injury.
 - > Always switch off the coffee machine and unplug the mains plug before reaching into the coffee grinder or the opening of the brewing unit.
-

 **CAUTION**



- > Never clean the bean hoppers in a dishwasher.
-

IMPORTANT

- * Slide the operating panel upward
The ON/OFF switch is on the right side, behind the operating panel.
- * Press the ON/OFF switch until coffee machine switches off
- * Disconnect mains plug
- * Turn the lock on the bean hopper 180° to open it



Rotate the lock by 180°

- * Lift bean hoppers out
- * Completely empty bean hoppers and wipe out thoroughly with a damp cloth
- * Allow bean hoppers to dry completely
- * Refill and replace bean hoppers
- * Turn the lock on the bean hopper 180° to lock it



5.5.9 Clean the powder hopper

The powder hopper should be cleaned when needed and at regular intervals.

Recommendation: monthly.

Clean more frequently depending on the powder used.

- * Slide the operating panel upward
The ON/OFF switch is on the right side, behind the operating panel.



- * Press the ON/OFF switch until coffee machine switches off
- * Disconnect mains plug
- * Turn the lock on the powder hopper 180° to open it
- * Tip hopper backwards and remove upwards
- * Empty hopper completely



- * Unscrew union nut at front and rear
- * Pull out the dosing auger
- * Thoroughly wipe out hopper with a damp cloth
- * Thoroughly clean individual dosing auger components
- * Allow powder hopper and individual components to dry completely
- * Re-assemble and replace the dosing auger and screw on union nuts



*Portioner with individual parts.
Dosing auger*



Ensure correct orientation of discharge.

- * Refill and replace powder hopper
- * Turn the lock 180° to relock it

IMPORTANT

6 HACCP cleaning schedule

You are required by law to ensure that your customers are not subject to any health hazards as a consequence of the consumption of the food items you serve.

A HACCP cleaning schedule (Hazard Analysis Critical Control Points) for risk identification and assessment is required. You should perform a risk analysis on your premises. The aim of the analysis is to recognise and pre-empt food hygiene hazard points. For this purpose, monitoring and, where necessary, test procedures must be established and implemented.

With correct installation, care, maintenance, and cleaning, WMF coffee machines meet the requirements described above. If care and cleaning of the coffee machine is not carried out properly, dispensing milk beverages will constitute a food hygiene hazard point. Please observe the following points in order to comply with the HACCP cleaning schedule:

Sanitise the milk system daily

- Follow the cleaning instructions for the milk system in the Care chapter. This will ensure that your system contains a minimum of bacteria at the commencement of operation.



"Food Hygiene Ordinance from 05.08.1997"

Use our HACCP cleaning schedule for monitoring of regular cleaning. HACCP export
▷ page 81

Use only cleaning agents that have been approved by WMF.

Follow the Care chapter
▷ starting on page 82



Call up the journal of the most recent cleaning operations via Information pad . The USB pad  can be used to export an HACCP journal.

TIP

Always commence operation with a freshly opened chilled milk pack

- Original packaged UHT milk is usually free from harmful bacteria. Always open a new chilled milk pack at commencement of operation.
- Ensure absolute cleanliness when opening the milk pack. Germs can be introduced from dirty hands or tools when opening.

Recommendation:

only use UHT milk with a 1.5% fat content.

Keep milk cool.

- Always have a new cooled milk pack handy.
- If cooling is not used during operation, then the milk must be used up very quickly. Cool the milk occasionally if needed.
- If little milk is used, chilled milk must be placed in the refrigerator again during operation.

At commencement of operation milk should be at approx. 6–8 °C.

Depending on the setting, one litre of milk is sufficient for approx. 20 cappuccinos.

WMF offers a range of refrigeration options (e.g., WMF countertop coolers).

HACCP cleaning schedule

Month _____ Year _____

Only use chilled UHT milk, to prevent health risks due to bacteria.
For powder beverages, use only products that have not exceeded their expiration date.

Cleaning steps:

1. Perform a system cleaning
 ▷ User Manual, Care chapter
- 2a. Clean the milk system manually (Easy Milk)
 ▷ User Manual, Care chapter
- 2b. Daily mixer rinsing
 ▷ User Manual, Care chapter
- 3a. Clean the milk system and change out the combi spout after 4 hours of operation time (absolutely required for a low number of dispense cycles, or if milk is non-chilled)
- 3b. Dynamic Milk: regularly clean the outside of the combi spout.
- 3c. Weekly mixer cleaning and regular cleaning of product hoppers (beans / powder) ▷ User Manual, Care chapter
4. General machine cleaning

Date	Cleaning steps				Signature
	1	2	3	4	
1.					
2.					
3.					
4.					
5.					
6.					
7.					
8.					
9.					
10.					
11.					
12.					
13.					
14.					
15.					
16.					

Date	Cleaning steps				Signature
	1	2	3	4	
17.					
18.					
19.					
20.					
21.					
22.					
23.					
24.					
25.					
26.					
27.					
28.					
29.					
30.					
31.					

7 Maintenance and descaling

Please observe that this is a professional industrial coffee machine which needs regular maintenance and descaling.

The maintenance date is based on the degree of use of the coffee machine and is shown on the display. If maintenance is undertaken by WMF Service, then descaling of the brewing system is done at the same time.

The coffee machine may continue to be operated after the message, but Customer Care or contract maintenance should be carried out promptly to ensure correct functioning and so as to avoid any subsequent damage.

7.1 Maintenance

Maintenance after the display message; may only be undertaken by trained personnel or by WMF Service, as in this instance components affecting safety must be replaced.

The following care or maintenance stages are provided:

- Maintenance after the display message; may only be undertaken by trained personnel or by WMF Service, as in this instance components affecting safety must be replaced.

Service maintenance message
▷ Messages and instructions
page 107

Service maintenance message
▷ Messages and instructions
page 107

7.2 WMF Service

You can reach WMF Service if the local service point is not known.

WMF GmbH
WMF Platz 1
D - 73312 Geislingen (Steige)

Important.


For other maintenance work and repairs, please contact your local WMF Service. The telephone number can be found on the address sticker on the coffee machine and on the delivery note.



8 Messages and instructions

8.1 Messages for operation

Refill beans

- * Refill bean hopper (refer to display)
- * Check:
 - Is the bean hopper lock open?
- ▷ *Care*
- Coffee beans do not feed through.
- * Stir with a large spoon and confirm with 

Open water supply

- * Turn on water tap and confirm

Empty grounds container

- * Empty grounds container

Grounds container missing

- * Replace the grounds container correctly

Change water filter

- * Change water filter

Follow water filter instructions.

- * Call WMF Service when needed

Call WMF Service

Error number is displayed

Error messages and malfunctions

▷ *page 108*

Service message

Service maintenance after the display shows a message.

- * Call WMF Service

Service messages are instructions.

It is generally possible to continue operating the coffee machine.

8.2 Error messages and malfunctions

Basic procedure on display of error messages or malfunctions.


- * Switch coffee machine off and then on again after a few seconds
- * Repeat the process which led to the error

In many cases, this eliminates the malfunction and you can continue working.

If this is not successful: find the error message or error number in the following error list and follow the action instructions indicated.

If this does not rectify the error or if the error indicated is not listed please call WMF Service.

Some messages lead to blocking of individual functions. You will notice this by the fact that the beverage button illumination goes out. The beverage buttons that are still illuminated can continue to be used.

Your WMF 5000 S+ is provided with a diagnostics program. Any errors that occur are shown on the display. The error messages listed may also be caused by an interruption to the mains electricity supply. If there is a current error or a message to the operator, the  pad is displayed.

- * Touch 

The error message and the error number are displayed.



The ON/OFF switch reacts after about 1 second and the coffee machine switches off.

In order to clear an error, for example if the software hangs up, pressing and holding the ON/OFF switch will switch off the controller.

Afterwards, switch the coffee machine on again.

NOTE

Error number	Error description	Action instructions
88	Boiler: over-temperature	<ul style="list-style-type: none"> ✳ Switch the coffee machine off, allow to cool and switch on again ✳ If error not remedied call WMF Service
161	Flow error: brewing water	<p><i>Between each of the following steps switch off the coffee machine and on again. If error not remedied carry out the next step.</i></p> <ul style="list-style-type: none"> ✳ Set the grinding degree coarser ▷ Software ▷ System ▷ Set grinding degree, page 73 ✳ Reduce quality ▷ Settings ▷ Recipes, page 49 ✳ If error not remedied call WMF Service
186	Steam boiler: level	<p><i>Beverage dispensing temporarily blocked.</i></p> <ul style="list-style-type: none"> ✳ Switch the coffee machine off and on again ✳ Check whether the main tap for the water inlet pipe is open
188	Heater error	<ul style="list-style-type: none"> ✳ Switch off the coffee machine, disconnect mains plug ✳ Call WMF Service
9083	Cooler temperature is in the frost range	<ul style="list-style-type: none"> ✳ Check whether the cooler temperature is set too low
9507	Flow error: water pressure missing	<ul style="list-style-type: none"> ✳ Open the water tap or fill up the water tank ✳ If error not remedied call WMF Service

Error number	Error description	Action instructions
9678 9679 9619	Right grinder blocked Left grinder blocked	<ul style="list-style-type: none"> * Switch off the coffee machine * Disconnect mains plug * Remove bean hopper * Rotate the grinder disk counterclockwise only by using the multitool for the hopper (two pins must be inserted in the corresponding recesses on the grinder) ▷ Care ▷ Clean the bean hopper, page 100 * Replace hopper * Switch on the coffee machine <p>If this occurs frequently:</p> <ul style="list-style-type: none"> * Set grinding degree one stage coarser ▷ Software ▷ System ▷ Set grinding degree, page 73



8.3 Errors without error message

Error pattern	Action instructions
<ul style="list-style-type: none"> • No Choc dispensing but water in grounds container 	<ul style="list-style-type: none"> * Do not use Choc dispensing * Call WMF Service (coffee dispensing possible)
<ul style="list-style-type: none"> • Choc portioner blocked, Choc dispensed only with water 	<ul style="list-style-type: none"> * Clean the portioner ▷ Care ▷ Clean the powder hopper, page 101 * Empty powder * Turn dosing auger manually until all powder is removed * If necessary rinse with water * Allow all parts to dry completely
<ul style="list-style-type: none"> • Loud noise when Choc is being dispensed 	<ul style="list-style-type: none"> * Remove the mixer bowl * Check whether the mixer wheel has been installed correctly ▷ Care ▷ Clean the mixer, page 97 * Replace the mixer wheel if needed
<ul style="list-style-type: none"> • Coffee dispensing on the left / right differs 	<ul style="list-style-type: none"> * Clean the combi spout ▷ Care ▷ Clean the milk system manually, page 95

Error pattern	Action instructions
<ul style="list-style-type: none"> No milk foam / no milk dispensing, but milk in the milk container 	<ul style="list-style-type: none"> Check whether the milk hose is kinked or squashed Re-route milk hose correctly Easy Milk: clean the combi spout Dynamic Milk: clean the combi spout manually Dynamic Milk: refill milk and touch "Milk system refill" in the customer care menu ▷ Software ▷ Care ▷ Milk system refill, page 43 Check whether milk cooler is iced
<ul style="list-style-type: none"> AutoClean Plug&Clean adapter can no longer be plugged in or locked 	<ul style="list-style-type: none"> Check that the disc is seated properly in the Plug&Clean socket <p>The disc can rotate out of position.</p>
<ul style="list-style-type: none"> Milk foam not OK Temperature too cold or too hot 	<p>Dynamic Milk</p> <ul style="list-style-type: none"> Perform a quality check <p>This function is enabled for trained staff only. Contact the Service department if needed.</p> <p>Easy Milk</p> <ul style="list-style-type: none"> Check whether the milk temperature is the same as the set temperature Clean the combi spout <p>▷ Care ▷ Clean the milk system manually, page 95</p>
<ul style="list-style-type: none"> The milk foam dispensing sputters severely Milk too hot 	<ul style="list-style-type: none"> Check whether the milk system has been cleaned Clean the milk system ▷ Care ▷ Clean the milk system manually, page 95 Check whether the milk has been cooled sufficiently
<ul style="list-style-type: none"> No powder beverage dispensing 	<ul style="list-style-type: none"> Clean the mixer bowl Is the hose kinked? Perform milk cleaning and rinsing more often, if necessary daily ▷ Care ▷ Clean the mixer, page 97 Use lower powder dosage Use higher water dosage

<i>Error pattern</i>	<i>Action instructions</i>
<ul style="list-style-type: none"> • Pump runs continuously, water in grounds container 	<ul style="list-style-type: none"> * Switch the coffee machine off and on again * If error not remedied call WMF Service
<ul style="list-style-type: none"> • Choc hopper cannot be replaced 	<ul style="list-style-type: none"> * Manually turn the drive for the dosing auger at the portioner slightly in a clockwise direction * Check whether Choc hopper is accidentally locked
<ul style="list-style-type: none"> • Bean hopper cannot be replaced 	<ul style="list-style-type: none"> * Check whether bean hopper is accidentally locked * Check whether there are any beans between the grinder and the hopper

9 Safety and warranty

9.1 Hazards to the coffee machine



Follow the manual

Failure to follow this and resultant damage will result in loss of liability.

Follow the conditions for use and installation.

Installation location

- The installation location must be dry and protected against water spray.
- Some condensate, water, or steam can always be discharged from a coffee machine.
 - > Do not use the coffee machine outdoors.
 - > Set up the coffee machine so that it is protected against water spray.
 - > Always place the coffee machine on a water-resistant and heatproof base in order to protect the installation surface against damage.

Coffee grinder

- Foreign objects can damage the grinders. Such damage is not covered under the warranty.
 - > Ensure that no foreign objects land in the coffee bean hopper.

IMPORTANT

*Follow the Warranty chapter
> starting on page 117*

*Conditions for use and installation
> starting on page 17*

Please observe the following instructions so as to prevent problems with and damage to the coffee machine:

- For drinking water with carbonate hardness from 5 °dKH or higher, a WMF water filter must be fitted. Failing to use the water filter recommended by WMF Service may damage the coffee machine (e.g. due to scale deposits).

- For insurance reasons always ensure that, at the end of operation, the mains switch is switched off or the device is unplugged. For machines with a constant water supply, the water mains tap for the inlet pipe must be closed.
- We recommend damage prevention measures, such as:
 - installation of a suitable water monitor in the mains water supply
 - installation of smoke alarms
- After a company holiday (several days or weeks) we recommend running the cleaning mode at least twice before reusing the machine.

System cleaning
▷ *Cleaning programs*
starting on page 85

9.2 Directives

Manufacturer: WMF GmbH, 73312 Geislingen (Germany)

The device fulfils the requirements of all applicable regulations in the directives MD (MRL) 2006/42/EC, EMV directive (EMC) 2014/30/EU and RoHS 2011/65/EU.

The manufacturer indicated above declares that this machine conforms to all applicable provisions of the directives listed. Any modifications to the machines that are not approved by us will cause this declaration to become invalid. Collecting technical documentation: WMF GmbH.

The original declaration of conformity is included with the machine. The device bears the CE mark.

The device fulfils the requirements of the German Food and Feed Code (LFGB), the Regulation on Commodities (BedGgstV), the EU regulation No. 10/2011 as well as the EC regulation No. 1935/2004 in the currently valid editions.

When used properly, the device does not present a health hazard or other unreasonable hazard. The materials and raw materials used fulflls the requirements of the Regulation on Commodities as well as the EU regulations No. 10/2011.

This device is subject to the directive on waste electrical and electronic equipment WEEE 2012/19/EU and may not be disposed of as domestic waste. Requirements traceability pursuant to EC regulation No. 1935/2004 and Good Manufacturing Practice within the meaning of EC regulation No. 2023/2006 are ensured and guaranteed. Currently valid country-specific regulations apply in countries outside of the European Union.



*For disposal please contact
WMF Service.*

*Address
▷ page 106*

9.3 Duties of the owner / operator

The operator of such equipment must ensure regular maintenance by WMF Service technicians, their agents or other authorised persons, and checking of safety devices.

Access to the service area is permitted only for persons with knowledge of and practical experience with the device, especially regarding safety and hygiene.

The coffee machine must be set up by the operator such that care and maintenance can be performed without hindrance.

In office / floor kitchen areas or similar self-service set-ups, only staff instructed in operation of the coffee machine should supervise the coffee machine. Trained personnel should carry out care procedures and be available for questions regarding use.

The operator shall ensure that electrical equipment and operating facilities are in a fit state (e.g., to DGUV Regulation 3) [German Accident Prevention Association or equivalent]. In order to ensure the operating safety of your coffee machine, it is essential to perform regular checks of the safety valves and the pressure containers, among other checks.

These measures are conducted by WMF Service or by WMF authorised service personnel as part of the maintenance work.

Machine cleaning must be carried out using only the WMF special cleaning agent intended by WMF for the coffee machine, and for the milk system.

The manufacturer's specifications regarding maintenance cycles and frequency of maintenance (▷ Maintenance) must be followed.

Cleaning intervals overview

▷ page 84

HACCP

▷ page 103

WMF special cleaning agent

▷ Accessories and spare parts
page 122

9.4 Warranty claims



Follow the manual

- Failure to follow this and resultant damage will result in loss of liability.
- > Follow the conditions for use and installation.

IMPORTANT

*Conditions for use and installation
▷ starting on page 17*

Whether the purchaser has any rights under warranty, and the nature of any such warranty rights that the purchaser may have, is determined by the agreement made between the purchaser and the vendor. If the requirements of this User Manual are not followed, warranty claims will not be recognised.

No warranty is provided:

- On any parts subject to natural wear and tear. This includes seals, mixers, and brewing unit, among other items.
- For malfunctions due to the effect of the weather, scale build-up, chemical, physical, electrochemical, or electrical effects.
- If a water filter is not fitted even though the local water supply requires use of a water filter and malfunctions occur as a consequence.
- If malfunctions occur as a result of failure to follow instructions for the handling, maintenance, and care of the unit (e.g., User Manual and maintenance instructions).
- With respect to faults which occur as the result of failure to use original WMF spare parts or incorrect assembly by the purchaser or by third parties or by faulty or negligent treatment.
- With respect to the consequences of improper modifications undertaken without the consent of WMF, or by repair or reconditioning work on the part of the purchaser or by third parties.
- With respect to faults caused by inappropriate or improper use.

Important

*Maintenance
▷ page 105*

Appendix: Technical data

Technical data for coffee machine

External dimensions	Width 325 mm Height 716 mm (with lockable bean hopper) Depth 590 mm
Coffee bean hopper	approx. 1,100 g per load ⁽¹⁾
Powder hopper (optional)	Coffee bean hopper in the center approx. 700 g ⁽¹⁾ approx. 2,000 g ⁽²⁾
Weight empty	approx. 37 kg (depending on the model)
Water supply	3/8 inch hose connector with water mains tap, and dirt filter with 0.08 mm mesh size, on-site. ⁽³⁾ At least 0.2 MPa (2 bar) supply pressure at 2 l/min. Maximum 0.6 MPa (6 bar). Important. If the customer's on-site flow pressure exceeds 0.6 MPa (6 bar), then a pressure reducer must absolutely be connected upstream and set to a maximum of 0.6 MPa (6 bar). Maximum inlet temperature 35 °C. The set of hoses provided with the new coffee machine, the constant water supply kit, or the new water filter must be used. Do not use the old set of hoses.
Water quality	For drinking water with carbonate hardness from 5 °dKH or higher, a WMF water filter must be fitted.
Water drain tube (optional)	Hose a minimum of DN 19, minimum downward slope of 2 cm/m
Use at elevation above sea level	<2,000 m

We reserve the right to make technical modifications.

⁽¹⁾ The capacity depends on the size of the coffee beans.

⁽²⁾ Only with optional powder hopper. The capacity depends on the powder used.

⁽³⁾ These specifications (IEC 60335-2-75) for the water connection to the coffee machine apply in EU member states. It may be necessary to also observe additional country-specific regulations. Outside the EU countries acceptance of the standards quoted is to be checked by the legal entity or natural person who wishes to use the coffee machine.

Nominal power rating	2.75–3.25 kW	9 kW
Power supply	220–240 V, 50/60 Hz, (1/N/PE)	380–415 V, 50/60 Hz, (3/N/PE)
Illumination	LED	
Degree of protection	IP X0	
Protection class	class 1	
Calibration pressure	Boiler 1.6 MPa (16 bar) Steam boiler 0.5 MPa (5 bar)	
Continuous sound pressure level (Lpa)	<70 dB(A) ⁽⁴⁾	
Ambient temperature	+5 °C to maximum +35 °C (empty the water system in case of frost).	
Maximum humidity	80% relative humidity without condensation. Do not use unit outdoors.	
Installation surface / water spray	The device must be placed and levelled on a horizontal, sturdy, water-resistant, and heatproof base. The device must not be cleaned using a water jet. The device must be installed where it is protected against water spray. The device must not be located on a surface that is sprayed or cleaned with a water hose, steam jets, steam cleaner, or similar devices.	

We reserve the right to make technical modifications.

⁽⁴⁾ A-evaluated sound pressure level Lpa (slow) and Lpa (impulses) at operating personnel workplace is under 70 dB(A) in any working mode.

Installation clearances	<p>For operating, service, and safety reasons the machine should be installed with a clearance from the building or non-WMF components of not less than 50 mm at the sides and 50 mm at the back.</p> <p>A minimum working space of 800 mm in front the coffee machine and overhead clearance of at least 200 mm above the product hoppers are recommended. A clear height of 1,100 mm from the top of the supporting surface should be ensured. The height of the installation surface above the floor is at least 850 mm. If the coffee machine connections are to be run downwards through the counter, please make space for the lines, which can reduce the usable space below the machine.</p>
Installation dimensions of the water filter	See the User Manual for the water filter.

We reserve the right to make technical modifications.

These specifications for the electrical connection and the standards quoted apply for connecting the coffee machine in EU countries. It may be necessary to also observe additional country-specific regulations. Outside the EU countries acceptance of the standards quoted is to be checked by the legal entity or natural person who wishes to use the coffee machine.

The customer's on-site electrical system must be designed to meet country-specific regulations per IEC 60364 and must match the information on the rating plate.

An isolated ground socket or a country-specific single-phase socket for single-phase connection, or a 5-pole CEE / CEKON socket per DIN EN 50310 VDE 0800-2-310 or a country-specific multi-pole socket for a three-phase connection, must be available near the machine. The sockets are part of the customer's on-site installation. The power cord must not come into contact with hot surfaces. If the power cord for this device is damaged then it must be replaced by our service personnel or a similarly qualified person, in order to prevent hazards.

In order to avoid possible faults from arising in our shielded data lines due to potential equalisation currents between the devices, an additional potential equalisation unit should be planned for devices connected to the vending system (see DIN EN 50310 VDE 0800-2-310).

If the machine is intended to be installed in a large kitchen, it is recommended that it be equipped with a ground potential bonding conductor. The potential equalisation terminal is installed by WMF Service when needed.

Appendix: Accessories and spare parts

Number	Unit	Designation	Order No.	Model
Water supply				
1	Pcs	Connecting tube for constant water supply	33 2292 1000	all
1	Pcs	Angle for drain tube	33 2165 8000	all
1.5	Meter	Drain tube	00 0048 0042	all
Tool				
1	Pcs	Multitool	33 2408 4000	all
Product hopper				
1	Pcs	Bean hopper and powder hopper lid	33 2655 7099	all
1	Pcs	Medium bean hopper lid	33 2655 8099	all
1	Pcs	Bean hopper / product hopper labels	33 2624 7000	all
Milk and mixer system				
1	Pcs	Double foamer, complete	33 2867 5300	Easy Milk
1	Pcs	Milk restrictor	33 2614 9000	Easy Milk
1	Meter	Milk hose	00 0048 4948	all
1	Pcs	Milk hose spring	33 0190 3000	all
1	Pcs	Milk hose sleeve	33 2180 5000	all
1	Pcs	Plug&Clean adapter	33 2427 5000	all
1	Pcs	Mixer bowl	33 2895 4000	Powder
1	Pcs	Mixer wheel	33 2895 5000	Powder
0.25	Meter	Mixer hose	00 0048 0064	Powder
Drip tray / drip grid				
1	Pcs	Drip tray with SteamJet	33 2633 7100	with SteamJet
1	Pcs	Drip tray without SteamJet	33 2633 7000	without SteamJet
1	Pcs	Drip grid with SteamJet	33 2633 8100	with SteamJet
1	Pcs	Drip grid without SteamJet	33 2633 8000	without SteamJet

Number	Unit	Designation	Order No.	Model
WMF customer care program				
1	Pack	Special cleaning tablets (100 pieces)	33 2332 4000	all
1	Pack	Special cleaning tablets for the milk system	33 2622 0000	all
1	Pcs	Cleaning container for the milk system	33 2593 6000	all
1	Pcs	Cleaning container lid for the milk system	33 2593 7000	all
1	Pcs	Pipe cleaner	33 0350 0000	all
1	Pcs	Cleaning brush	33 1521 9000	all
1	Tube	WMF Molykote "gasket grease"	33 2179 9000	all
1	Bottle	WMF Special cleaner for milk foamer	33 0683 6000	
4	Bottles	WMF milk system cleaning agent (AutoClean)	33 4748 1000	AutoClean
4	Cans	WMF cleaning granulate (AutoClean)	33 4745 4000	AutoClean
Documentation				
1	Pcs	Set of documents WMF 5000 S+	33 4186 6010	all

Index

A

Accessories and spare parts 122
Accounting 61
Accounting PIN 63
Add cleaning agent (AutoClean) 92
Additions 47
Animations 43
AutoClean cleaning cycle 66
Automatic cup detection 21
Automatic height adjustment 32
Auto Steam 30

B

Barista pad 21, 53
Barista pad - coffee strength 39
Bean hopper 21
Bean hopper / powder hopper 32
Beverage buttons 21, 38
Beverage dispensing 27
Beverage pre-selection 58
Beverages 44
Beverages: Font + colour 71
Bluetooth 73
Brewing pressure display 73
Button layout 56
Button layout timer 66

C

Caffeine-free 57
Cancel beverage 27, 58
Carbonate hardness 71
Care 41, 60, 82
Care safety instructions 82
Change addition 48
Change buttons 52
Change recipes 47
Chilled coffee 48
Cleaning intervals 84
Cleaning PIN 63
Cleaning programs 85
CleanLock 42
Clean the Auto Steam outlet 98
Clean the bean hopper 100
Clean the combi spout manually (Dynamic Milk) 97
Clean the cup sensor 95
Clean the drip tray 94
Clean the grounds container 94
Clean the housing 95
Clean the milk system manually 95
Clean the milk system manually (Easy Milk) 95
Clean the mixer 97
Clean the operating panel (CleanLock) 93
Clean the Plug&Clean socket (AutoClean) 97
Clean the powder hopper 101
Coffee cleaning granulate 92
Coffee quality 49
Combi spout with integrated milk foamer 21
Comments on the recipe 50

Conditions for use and installation 17
Cool milk 26
Correction of spout position 75
Counters 61
Cup detection 75
Cup detection (optional) 32
Cup height tolerance 75
Cup size 55
Cup size adjustment 28, 39
Cup volume 45, 55
Cup volume selection 28
Cup volume S-M-L 45
Cup warmer 21, 31
Current recipe composition 47
Customer cups 77
Customer's logo 59

D

Daily timer overview 65
Data back-up 81
Daylight saving time 67
Decaf 40
Decaf factor 57
Decrease display brightness 70
Delete addition 48
Delete timer 65
Descaling 60
Digital solutions 78
Directives 114
Dispensing option 46
Dispensing test 44
Display and illumination 69
Display background 70
Display brightness 70
Display for beverage buttons and settings 21
Drip tray 35
Duties of the owner / operator 116
Dynamic Milk foam quality levels 49

E

Easy Steam 30
Eco mode 67, 72, 79
Error message 55
Error messages and malfunctions 108
Errors without error message 110
Event display 70
Export counters 80
External accounting 61

F

FFC 48
FFC filter change 42, 91
Filter capacity 72
Firmware update 81
Foamer rinsing 90
Foamer rinsing (Dynamic Milk) 90
Freeflow 46
Free of charge settings 62
Fresh Filtered Coffee - FFC (optional) 21, 27
Function bar 38
Function bar "Ready to operate" display 36

G

General safety instructions 7
Glossary 23
Grinding degree setting 73
Ground coffee quantity 48
Grounds container 21, 34
Grounds disposal through the counter (optional) 34

H

HACCP cleaning schedule 103
HACCP export 81
Hazards to the coffee machine 113
Height adjustment of the combi spout 32
Hopper lock 21
Hot water button 38
Hot water dispensing 28
Hot water spout 21

I

Illumination 69
Information 60
Installation clearances 120
Installation surface 119
Instructions 43
Intended use 14
Intensive system cleaning (AutoClean) 42
Introduction 20
Inventory of factory additions 47

J

Journal 60

L

Language 78
Language pre-selection 56
Last brewing cycle 60
Load beverage symbols 80
Load data 81
Load language 81
Load recipes 44, 80
Lock recipes 44
Logo 59

M

Main menu functions 37
Maintenance 105
Maintenance and descaling 105
Manual cleaning 93
Manual insert 33
Manufacturer's logo 59
Measured carbonate hardness 71
Measured total hardness 72
Menu control pads 37
Menu pad 21, 54
Messages and instructions 107

Messages for operation 107
Messages on the display 37
Metered 46
Milk foam dispensing 26
Milk foam selection 58
Milk (optional) 74
Milk or milk foam dispensing 26
Milk quantity 48
Milk storage temperature 68
Milk system cleaner 92
Milk system cleaning 41, 42, 89
Milk system refill 40, 43, 56
Mixer rinsing 41, 91
Mode 76
Multiple brewing cycles 46

N

Nominal power rating 119
No warranty is provided: 117
Nutritional information 39, 54, 75

O

ON/OFF switch 21
Operating elements 53
Operating options 53
Operating panel 21
Operation 24
Operation safety instructions 24
Optional pads 28
Overview 36

P

Parts of the coffee machine 20
PIN rights 62
Portioner 73
PostSelection 57
Powder hopper (optional) 21
Preparation of ground coffee using the manual insert 33
Preparing the milk system after cleaning 43
Pre-selection pads (optional) 28
Progress display 69

Q

Quality check (Dynamic Milk) 69
Quality level 49

R

Rapid rinsing (AutoClean) 88
Ready to operate 36
"Ready to operate" display 20, 21, 38
Re-enter PIN 63
Remote actions 78
Removable drip tray with drip grid 21

Index

S

Safety 7
Safety devices 7
Save recipes 80
Save recipes as pdf files 80
Second milk type (optional) 40, 55
Second type of coffee 40
Select coffee grinder 50
Self-service 53
Self-service mode 53
Service 60
Set the cup height manually 51
Set timer switching times 65
Settings 43
Settings PIN 63
Side illumination 21
Size setting S-M-L 76
Smart Remote 78
S-M-L Function 45, 74
S-M-L pad 39
Software 36
Start-Stop 46
Start-Stop-Freeflow 46
Steam button 40
Steam dispensing (optional) 29
SteamJet 21, 54
SteamJet pad 21, 31, 38
Steam outlet 21
Switch off 35
Switch-off rinsing 43
Switch on the coffee machine 26
Syrup (optional) 74
Syrup station option 25
System 68
System cleaning 41, 85, 87, 88

T

Tablet insert 21
Technical data 118
Technical data for coffee machine 118
Temperature 72
Text and picture 50
Time/date 64
Timer 60, 64
Timer overview and setting the timer 64
Time zone 67
Total hardness 72
Touch display calibration 70

U

USB 80
User Manual Signs and Symbols 22
User Manual Symbols 22

V

Vending machines 61

W

"Warm rinse" pad 21, 39, 54
Warranty claims 117
Water filter 60, 71
Water quality 118
Water quantity 48
Water supply 118
WMF Service 106

Your nearest WMF Service:

© 2018–2021 WMF GmbH

All rights reserved, in particular duplication, distribution and translation rights. No part of this manual may be reproduced in any form or processed, duplicated or distributed using electronic systems without written consent.

Design and production / typesetting and print presentation:
TecDoc GmbH; Geislingen, info@tecdocgmbh.de
Original User Manual. Printed in Germany.

We reserve the right to make technical modifications.
21.05.2021



DESIGNED TO PERFORM