



SINCE 1888

ALLFLAME PEER 3 ALLFLAME PRIME 4 ALLFLAME HERO 4/6



Abb.: ALLFLAME HERO 4

Art-Nr. 251051 / 251052 / 251053 / 251054 / 251055 / 251056 / 251057 / 251058


support@roesle.de
www.roesle.com

DE	Montageanleitung
EN	Assembly Instructions
FR	Guide d'assemblage
NL	Gebruiksaanwijzing
IT	Istruzioni d'uso





ALLFLAME PEER 3



10.2024





ALLFLAME PEER 3



A (7x)



B (2x)



C (16x)



D (4x)



E (18x)



F (8x)



G (8x)




H (2x)



I (4x)






J (5x)



PH 2




2x
SW 17 mm





ALLFLAME PRIME 4



10.2024



ALLFLAME PRIME 4



A (7x)



B (2x)



C (16x)



D (6x)



E (18x)



F (2x)



G (1x)




H (4x)




I (4x)






J (5x)



PH 2




2x
SW 17 mm





ALLFLAME HERO 4





ALLFLAME HERO 4



A (7x)



B (2x)



C (16x)



D (6x)



E (18x)



F (2x)



G (1x)




H (4x)




I (4x)






J (5x)



PH 2




2x
SW 17 mm





ALLFLAME HERO 6





ALLFLAME HERO 6



A (7x)



B (2x)



C (16x)



D (6x)



E (18x)



F (2x)



G (1x)




H (4x)



I (4x)






J (5x)



PH 2




2x
SW 17 mm






1

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



2

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6




10.2024




3

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



4

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



10.2024








5

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6







PH 2



6

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



6x A 



PH 2









7

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



PH 2





10.2024





8

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



9


ALLFLAME PRIME 4
ALLFLAME HERO 4/6







10

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



11

ALLFLAME PRIME 4
ALLFLAME HERO 4/6




10.2024




12

ALLFLAME PEER 3



13

ALLFLAME PEER 3




10.2024







14

ALLFLAME PEER 3



15

ALLFLAME PEER 3




10.2024




16

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



17

ALLFLAME PRIME 4
ALLFLAME HERO 4/6



10.2024




18

ALLFLAME PRIME 4
ALLFLAME HERO 4/6




1x G
2x C



19

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6

2x B





10.2024




20

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6



21

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6




10.2024




22

ALLFLAME PRIME 4
ALLFLAME HERO 4/6



23

ALLFLAME PRIME 4
ALLFLAME HERO 4/6




10.2024



24


ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6

i



25

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6




10.2024




26

ALLFLAME PEER 3



27

ALLFLAME PRIME 4
ALLFLAME HERO 4




10.2024



28


ALLFLAME HERO 6



29

ALLFLAME PEER 3
ALLFLAME PRIME 4
ALLFLAME HERO 4/6


SW 17
2x







30

1






2

50mbar



3

30mbar







10.2024





RÖSLE GmbH & Co. KG

Johann-Georg-Fendt-Straße 38
87616 Marktoberdorf
Germany

Phone: +49 8342 912-0

Fax: +49 8342 912-190

E-Mail: support@roesle.de

Web: www.roesle.com

Version 1

Oktober 2024

